

Product Usage Instructions

BadgeMaster

WashAway Stabilizer

FREESTANDING DESIGN INSTRUCTIONS:

- Cut one piece of BadgeMaster and one piece of AquaMesh approximately 2" larger than your hoop.
- Note: BadgeMaster is frequently combined with AquaMesh for stitch intensive designs and to add stiffness to freestanding structures.
- Hoop all layers as one and stitch the design.
- Follow removal instructions to remove excess stabilizer.

REMOVAL INSTRUCTIONS:

- Remove the embroidery from the hoop.
- Trim excess BadgeMaster, leaving about 1/4" of stabilizer around the design.
- Rinse any remaining stabilizer away with warm running water.
- For a stiff effect, as in stand-alone lace, do not rinse away all of the BadgeMaster.



www.OESD.com