

Product Usage Instructions

HydroStick TearAway Stabilizer

- Cut a piece of HydroStick TearAway 2" larger than your hoop.
- Hoop the HydroStick TearAway with the glue side up. (The glue side is shiny.)
- To activate the adhesive, LIGHTLY moisten the entire glue side of the hooped stabilizer with water using a damp foam brush, damp sponge, or a light misting spray.
- Avoid using too much water, just a little creates a firm hold. Oversaturating will result in too much adhesive and an extended drying time before stitching.
- Position the item onto the stabilizer. Gently finger press into place. Let the stabilizer dry before putting the hoop in the machine.
- Embroider the item.

REMOVAL INSTRUCTIONS:

- Remove the embroidered item and stabilizer from the hoop.
- To remove the embroidered item from the stabilizer, reactivate the adhesive with water. Place the item with the stabilizer side down on a flat surface. Gently lift the embroidered item and re-moisten the stabilizer with water. Continue to lift and moisten until the adhesive is released completely from the item.
- If item appears stiff, rinse under warm running water to remove any excess adhesive.
- Gently tear away any excess stabilizer while supporting the stitches between your thumb and finger.