

# FREESTANDING LACE HAUNTED HOUSE



**1**  
Design

Fits hoop sizes 6" x 10" and larger



# THREAD LIST



## Isacord Thread Colors

0020 Black

## DESIGNS

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**



### 12480-01 Haunted Front Door Wall Applique

Size Inches:                      Size mm:                      Stitch Count:  
**2.86 X 6.98 in. 72.64 X 177.29 mm 23,167 St.**

- 1. Wall Placement Stitch..... 0020
- 2. Wall Cut Line & Tackdown..... 0020
- 3. Door Placement Stitch..... 0020
- 4. Door Cut Line & Tackdown..... 0020
- 5. Windows Placement Stitch..... 0020
- 6. Windows Cut Line & Tackdown ..... 0020
- 7. Lace..... 0020

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**

### 12480-02 Haunted Right Wall Applique

Size Inches:                      Size mm:                      Stitch Count:  
**6.02 X 4.38 in. 152.91 X 111.25 mm 32,102 St.**




- 1. Wall Placement Stitch..... 0020
- 2. Wall Cut Line & Tackdown..... 0020
- 3. Ghost Placement Stitch..... 0020
- 4. Ghost Cut Line & Tackdown ..... 0020
- 5. Windows Placement Stitch..... 0020
- 6. Windows Cut Line & Tackdown ..... 0020
- 7. Lace..... 0020

**\*Fabric Required**

### 12480-03 Haunted Back Wall Applique

Size Inches:                      Size mm:                      Stitch Count:  
**2.86 X 7.00 in. 72.64 X 177.80 mm 11,512 St.**



- 1. Wall Placement Stitch..... 0020
- 2. Wall Cut Line & Tackdown..... 0020
- 3. Lace..... 0020

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**

## 12480-04 Haunted Inner Wall Applique

Size Inches:                      Size mm:                      Stitch Count:  
**6.04 X 4.77 in. 153.42 X 121.16 mm 41,654 St.**

- 1. Wall Placement Stitch..... 0020
- 2. Wall Cut Line & Tackdown..... 0020
- 3. Lace..... 0020




**\*Fabric Required**

## 12480-05 Haunted Roof 1 Applique

Size Inches:                      Size mm:                      Stitch Count:  
**6.65 X 4.43 in. 168.91 X 112.52 mm 29,072 St.**

- 1. Roof Placement Stitch..... 0020
- 2. Roof Cut Line & Tackdown..... 0020
- 3. Lace..... 0020






Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**

## 12480-06 Haunted Roof 2 Applique

Size Inches:                      Size mm:                      Stitch Count:  
**6.66 X 3.73 in. 169.16 X 94.74 mm 29,147 St.**

- 1. Roof Placement Stitch..... 0020
- 2. Roof Cut Line & Tackdown..... 0020
- 3. Lace..... 0020



**\*Fabric Required**

## 12480-07 Haunted Front Wall Applique

Size Inches:                      Size mm:                      Stitch Count:  
**4.76 X 4.37 in. 120.90 X 111.00 mm 28,236 St.**

- 1. Wall Placement Stitch..... 0020
- 2. Wall Cut Line & Tackdown..... 0020
- 3. Window Placement Stitch..... 0020
- 4. Window Cut Line & Tackdown..... 0020
- 5. Lace..... 0020



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**



## 12480-08 Haunted Left Wall Applique

Size Inches:                      Size mm:                      Stitch Count:  
**4.77 X 5.87 in. 121.16 X 149.10 mm 37,807 St.**

- 1. Wall Placement Stitch..... 0020
- 2. Wall Cut Line & Tackdown..... 0020
- 3. Door Placement Stitch..... 0020
- 4. Door Cut Line & Tackdown..... 0020
- 5. Window Placement Stitch..... 0020
- 6. Window Cut Line & Tackdown..... 0020
- 7. Lace..... 0020

**\*Fabric Required**



## 12480-09 Haunted Back Door Wall Applique

Size Inches:                      Size mm:                      Stitch Count:  
**4.74 X 4.17 in. 120.40 X 105.92 mm 22,041 St.**

- 1. Wall Placement Stitch..... 0020
- 2. Wall Cut Line & Tackdown..... 0020
- 3. Door Placement Stitch..... 0020
- 4. Door Cut Line & Tackdown..... 0020
- 5. Window Placement Stitch..... 0020
- 6. Window Cut Line & Tackdown..... 0020
- 7. Lace..... 0020




Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**

### 12480-10 Haunted Roof 3 Applique

Size Inches:                      Size mm:                      Stitch Count:  
**5.17 X 3.61 in.    131.32 X 91.69 mm    20,911 St.**




- 1. Roof Placement Stitch..... 0020
- 2. Roof Cut Line & Tackdown ..... 0020
- 3. Lace..... 0020

**\*Fabric Required**

### 12480-11 Haunted Roof 4 Applique

Size Inches:                      Size mm:                      Stitch Count:  
**5.17 X 3.79 in.    131.32 X 96.27 mm    21,190 St.**




- 1. Roof Placement Stitch..... 0020
- 2. Roof Cut Line & Tackdown ..... 0020
- 3. Lace..... 0020

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**

### 12480-12 Haunted Upper Room Applique

Size Inches:                      Size mm:                      Stitch Count:  
**6.81 X 3.98 in. 172.97 X 101.09 mm 19,466 St.**




- 1. Tall Walls Placement Stitch ..... 0020
- 2. Tall Walls Cut Line & Tackdown..... 0020
- 3. Short Walls Placement Stitch ..... 0020
- 4. Short Walls Cut Line & Tackdown ..... 0020
- 5. Window Placement Stitch..... 0020
- 6. Window Cut Line & Tackdown ..... 0020
- 7. Lace..... 0020

**\*Fabric Required**

### 12480-13 Haunted Roof 5 Applique

Size Inches:                      Size mm:                      Stitch Count:  
**2.44 X 4.85 in. 61.98 X 123.19 mm 21,482 St.**



- 1. Roof Placement Stitch..... 0020
- 2. Long Side Cut Line & Tackdown ..... 0020
- 3. Short Side Cut Line & Tackdown..... 0020
- 4. Lace..... 0020



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**




### 12480-14 Haunted Foundation 1 Applique

Size Inches:                      Size mm:                      Stitch Count:  
**2.16 X 6.15 in.    54.86 X 156.21 mm    9,231 St.**

- 1. Floor Placement Stitch ..... 0020
- 2. Floor Cut Line & Tackdown ..... 0020
- 3. Lace..... 0020

**\*Fabric Required**



### 12480-15 Haunted Foundation 2 Applique

Size Inches:                      Size mm:                      Stitch Count:  
**4.53 X 4.53 in.    115.06 X 115.06 mm    12,076 St.**

- 1. Floor Placement Stitch ..... 0020
- 2. Floor Cut Line & Tackdown ..... 0020
- 3. Lace..... 0020

# COLLECTION SUPPLIES



## Stabilizer

- AquaMesh WashAway
- BadgeMaster
- StabliStick CutAway

## Supplies

- Fabric for Applique: deep purple for walls, gold organza for the windows, light charcoal for the roof and light gray for the doors about an 1/8 yd. of each color.
- Embroidery thread per chart
- Alligator Clamps
- Expert Embroidery Tape TearAway
- Optional: Button Clips



## NOTE

- The design in the photos is 12480-01. Applique techniques are the same for all of the designs. Stitch one of each design.
- Match bobbin thread to all top threads in the designs.


## STEP 1

- Cut applique fabrics slightly larger than needed. Prep fabric by applying 2 sheets of StabilStick CutAway to the wrong side of the cotton fabric. **DO NOT** apply StabilStick to the organza.
- Note – this stabilizes your fabric, so it produces a nice, crisp project.




## STEP 2

- Hoop 1 piece of AquaMesh and 1 piece of BadgeMaster.
- Stitch Machine Step 1, Wall Placement Stitch.




## STEP 3

- Place fabric over placement stitch, make sure to cover stitches completely.
- Optional – use Expert Embroidery Tape TearAway to hold items in place.
- Stitch Machine Step 2, the Wall Cut Line & Tackdown.
- Note - Gold thread used for visibility.



## STEP 4

- Remove hoop from machine, DO NOT unhoop fabric/stabilizer.
- Trim along cut line. Return the hoop to the machine.




## STEP 5

- Stitch Machine Step 3, the Door Placement Stitch.
- Place fabric over placement stitch as pictured, make sure to cover door placement completely.
- Tape in place.




## STEP 6

- Stitch Machine Step 4, the Door Cut Line and Tackdown.
- Remove hoop from machine, DO NOT unhoop fabric/stabilizer.



## STEP 7

- Trim along cut line.
- Return the hoop to the machine.



## STEP 8


- Stitch Machine Step 5, the Window Placement Stitch.






## STEP 9

- Place the organza fabric over placement stitch as pictured, make sure to cover the window placements completely.
- Stitch Machine Step 6, the Window Cut Line and Tackdown.



## STEP 10

- Remove hoop from machine, DO NOT unhoop fabric/stabilizer.
- Trim along cut line.
- Return the hoop to the machine.



## STEP 11

- Stitch Machine Step 7, the Black Lace & Detail.



## STEP 12

- Remove from hoop, trim the stabilizers  $\frac{1}{2}$ " away from the design. Be careful NOT to cut your eyelets or buttonettes!
- Wash away stabilizer and let dry face down.
- Tip: Rinse out the stabilizer in warm running water. Only rinse until it is slightly sticky. This will give the design more stiffness.





# ASSEMBLY



## STEP 1

- Connect right wall of the Upper Room (12480-12) with the back wall of the Upper Room by inserting the two buttonettes along the right wall into the two back wall eyelets.



## STEP 2

- Attach Roof 5 (12480-13) to the Upper Room walls – attach long side of roof to long slant by inserting the four buttonettes into the four eyelets and short side to the short slant by inserting the two buttonettes into the two eyelets.






# ASSEMBLY



## STEP 3

- Connect edge of Roof 3 (12480-10) to Roof 4 (12480-11) by inserting the four buttonettes into the four eyelets.



## STEP 4

- Connect front of the upper room structure (with window) into the two eyelets on Roof 3.



## STEP 5

- Connect back of the upper room structure into the two eyelets on Roof 4.



# ASSEMBLY

## STEP 6

- Set aside built upper room and left roof structure.




## STEP 7

- Connect left edge of Front Door Wall (12480-01) to the right edge of the Inner Wall. (12480-04)



## STEP 8

- Connect right edge of Front Door Wall (12480-01) to the left edge of the Right Wall.



## STEP 9

- Connect right edge of Back Wall (12480-03) to left edge of the Inner Wall (12480-04).
- Set aside built right room structure.



## STEP 10

- Connect edge of Roof 1 (12480-05) to edge of Roof 2 (12480-06) by inserting the four buttonettes into the four eyelets.



## STEP 11

- Connect left edge of Front Wall (12480-07) to right edge of Left Wall (12480-08) by inserting the three buttonettes into the three eyelets.





# ASSEMBLY




## STEP 12

- Connect left edge of Left Wall (12480-08) to right edge of Back Door Wall (12480-09) by inserting the three buttonettes into the three eyelets.



## STEP 13

- Connect the right edge of Front Wall (12480-07) into the three eyelets going down the right-side interior of the Inner Wall (12480-04) by inserting the three buttonettes into the three eyelets.



# ASSEMBLY




## STEP 14

- Connect the left edge of the Back Door Wall (12480-09) into the three holes going down the left side interior of the Inner Wall (12480-04) by inserting the three buttonettes into the three eyelets.



## STEP 15

- Connect right edge of Right Wall (12480-02) to left edge of Back Wall (12480-03) by inserting the three buttonettes into the three eyelets.





# ASSEMBLY




## STEP 16

- Connect top buttonette on left side of Front Door (12480-01) into eyelet at top right interior of Roof 2 (12480-06).




## STEP 17

- Connect top buttonette on right side of Back Wall (12480-03) into eyelet at top left interior of Roof 2 (12480-06).



## STEP 18


- Connect top edge of Inner Wall (12480-04) into eyelet at top left interior of Roof 2 (12480-06).





## STEP 19

- Connect remaining edge of Inner Wall (12480-04) in to eyelets at the bottom of Roof 2 (12480-06).
- Connect remaining buttonettes on left side of Front Door (12180-01) into eyelet on Roof 2 (12480-06).



## STEP 20

- Connect remaining buttonettes on right side of Back Wall (12480-03) into eyelets on Roof 2 (12480-06).



# ASSEMBLY



## STEP 21

- Connect Buttonette on top right of Front Wall (12480-07) into bottom right eyelet of Roof 3 (12480-10).




## STEP 22

- Connect buttonette on top left of Back Door Wall (12480-09) into bottom left eyelet of Roof 4 (12480-11).



## STEP 23

- Connect buttonettes on top right of Left Wall (12480-08) into eyelets of Roof 3 (12480-10).



# ASSEMBLY




## STEP 24

- Connect buttonettes on top right of Left Wall (12480-08) into eyelets on Roof 4 (12480-11).




## STEP 25

- Connect buttonette on top left of Front Wall (12480-07) into eyelet on Roof 3 (12480-10).
- Connect buttonette on top right of Back Door Wall (12480-09) into eyelet on Roof 4 (12480-11).
- Attach Left Roof Structure on Right Roof Structure
- Connect buttonette on right edge of Roof 3 (12480-10) into eyelet on Roof 2 (12480-06).



## STEP 26

- Connect buttonette on top right of Back Door Wall (12480-09) into eyelet on Roof 4 (12480-11).






# ASSEMBLY



## STEP 27

- Attach Roof 1 to Right Roof Structure.
- Connect buttonette on top right of Front Door Wall (12480-01) into top left eyelet of Roof 1 (12480-05).



## STEP 28

- Connect buttonette on top left of Back Wall (12480-03) into top right eyelet of Roof 1 (12480-05).




## STEP 29

- Connect buttonettes on top edge of Right Wall (12480-02) into eyelets on the bottom of Roof 1 (12480-05).



## STEP 30

- Connect remaining buttonette on right edge of Front Door Wall (12480-01) into eyelet on Roof 1 (12480-05).
- Connect remaining buttonette on left edge of Back Wall (12480-03) into eyelet on Roof a (12480-05).



## STEP 31

- Appliqué side facing up, connect buttonettes on Foundation 1 (12480-14) into eyelets of the right room structure except for the connection to the Inner Wall (12480-04).



## STEP 32

- Appliqué side facing up, connect buttonettes of Foundation 2 (12480-15) into eyelets of the left room structure except for the connection to the Inner Wall (12480-14).



## STEP 33

- Connect remaining buttonette on Foundation 1 into the eyelet that is aligned to the Inner Wall (12480-04).



## STEP 34


- Connect remaining buttonette on Foundation 2 into the eyelet that is aligned on the Inner Wall (12480-04).






# ATTENTION

When printing this document, any page scaling or page fitting options in your print dialog box must be turned OFF or set to NONE so that your files will print out at their actual size. Images not printed at actual size will not function as intended.




## TO SAVE PAPER



Only print the desired image by navigating to the image's page, go to File > Print and select "Current page" in the print dialog box. Repeat for each desired image.



# APPLIQUE PATTERNS







# APPLIQUE PATTERNS







# APPLIQUE PATTERNS







# APPLIQUE PATTERNS








# APPLIQUE PATTERNS



# APPLIQUE PATTERNS






# APPLIQUE PATTERNS










# APPLIQUE PATTERNS



# MIRRORED PATTERNS







# MIRRORED PATTERNS







# MIRRORED PATTERNS







# MIRRORED PATTERNS








# MIRRORED PATTERNS



# MIRRORED PATTERNS







# MIRRORED PATTERNS





# MIRRORED PATTERNS



# FREESTANDING HAUNTED HOUSE 2



1

Design

Fits hoop sizes 6" x 10" and larger

# THREAD LIST



## Isacord Thread Colors

- 0020 Black
- 1972 Silver Grey (or ISA Textlight Glow in the Dark thread)

## DESIGNS

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**



### 12641-01 Haunted Front Wall FSA

Size Inches:                      Size mm:                      Stitch Count:  
4.16 X 8.93 in.    105.66 X 226.82 mm    45,393 St.

- 1. Front Wall Placement Stitch ..... 0020
- 2. Cut Line & Tackdown ..... 0020
- 3. Windows Placement Stitch ..... 0020
- 4. Cut Line & Tackdown ..... 0020
- 5. Door Placement Stitch ..... 0020
- 6. Cut Line & Tackdown ..... 0020
- 7. Lace & Cover Stitch ..... 0020
- 8. Grey Linework ..... 1972



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

### 12641-02 Haunted Eaves FSL

Size Inches:                      Size mm:                      Stitch Count:  
**3.40 X 1.19 in.**      **86.36 X 30.23 mm**      **9,676 St.**

- 1. Eaves ..... 0020



**\*Fabric Required**



### 12641-03 Haunted Side Wall 1 FSA

Size Inches:                      Size mm:                      Stitch Count:  
**3.94 X 5.76 in.**      **100.08 X 146.30 mm**      **31,052 St.**

- 1. Side Wall Placement Stitch ..... 0020
- 2. Cut Line & Tackdown..... 0020
- 3. Window Placement Stitch..... 0020
- 4. Cut Line & Tackdown..... 0020
- 5. Lace & Cover Stitch..... 0020
- 6. Grey Linework ..... 1972



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**



**12641-04 Haunted Back Wall FSA**

Size Inches:                      Size mm:                      Stitch Count:  
**4.16 X 8.95 in.    105.66 X 227.33 mm    39,839 St.**

- 1. Back Wall Placement Stitch..... 0020
- 2. Cut Line & Tackdown..... 0020
- 3. Window Placement Stitch..... 0020
- 4. Cut Line & Tackdown..... 0020
- 5. Shutters & Door Placement Stitch..... 0020
- 6. Cut Line & Tackdown..... 0020
- 7. Lace & Cover Stitch..... 0020
- 8. Grey Linework ..... 1972

**\*Fabric Required**



**12641-05 Haunted Side Wall 2 FSA**

Size Inches:                      Size mm:                      Stitch Count:  
**3.92 X 6.64 in.    99.57 X 168.66 mm    36,511 St.**

- 1. Roof Placement Stitch..... 0020
- 2. Cut Line & Tackdown..... 0020
- 3. Lace & Cover Stitch..... 0020
- 4. Grey Linework ..... 1972

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**

### 12641-06 Haunted Roof 1 FSA

Size Inches:                      Size mm:                      Stitch Count:  
 5.45 X 5.10 in.    138.43 X 129.54 mm    48,783 St.

- 1. Roof Placement Stitch..... 0020
- 2. Cut Line & Tackdown..... 0020
- 3. Lace & Cover Stitch..... 0020
- 4. Grey Linework ..... 1972



**\*Fabric Required**

### 12641-07 Haunted Roof 2 FSA

Size Inches:                      Size mm:                      Stitch Count:  
 5.41 X 4.63 in.    137.41 X 117.60 mm    42,109 St.

- 1. Roof Placement Stitch..... 0020
- 2. Cut Line & Tackdown..... 0020
- 3. Lace & Cover Stitch..... 0020
- 4. Grey Linework ..... 1972




Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**

**12641-08 Haunted Chimney FSA**

Size Inches:                      Size mm:                      Stitch Count:  
**5.07 X 2.54 in.    128.78 X 64.52 mm    15,050 St.**

- 1. Chimney Placement Stitch ..... 0020
- 2. Cut Line & Tackdown..... 0020
- 3. Lace & Cover Stitch..... 0020




**\*Fabric Required**

**12641-09 Haunted Foundation FSA**


Size Inches:                      Size mm:                      Stitch Count:  
**3.24 X 3.23 in.    82.30 X 82.04 mm    9,399 St.**

- 1. Foundation Placement Stitch ..... 0020
- 2. Cut Line & Tackdown..... 0020
- 3. Lace & Cover Stitch..... 0020





Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



### 12641-10 Haunted Tree FSL

Size Inches:	Size mm:	Stitch Count:
4.91 X 6.71 in.	124.71 X 170.43 mm	33,641 St.

■ 1. Tree ..... 0020

### 12641-11 Haunted Tree Stand FSL

Size Inches:	Size mm:	Stitch Count:
1.95 X 2.38 in.	49.53 X 60.45 mm	8,706 St.

■ 1. Tree Stand ..... 0020






Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

### 12641-12 Haunted Fence FSL

Size Inches:	Size mm:	Stitch Count:
3.89 X 2.81 in.	98.81 X 71.37 mm	28,426 St.


■ 1. Fence Panel ..... 0020



### 12641-13 Haunted Fence Stand FSL

Size Inches:	Size mm:	Stitch Count:
1.62 X 1.99 in.	41.15 X 50.55 mm	8,018 St.

■ 1. Fence Stand ..... 0020



## Stabilizer

- AquaMesh WashAway
- BadgeMaster WashAway
- StabilStick CutAway

## Fabrics

- Wall fabric 1/8-yard (purple)
- Roof fabric 5" x 10" scrap (chartreuse)
- Doors/shutters fabric 5" x 5" scrap (orange)
- Windows fabric 6" x 6" fabric (white glow-in-the-dark)
- Apply two layers of StabilStick CutAway to the back of all fabrics.

## Supplies

- Expert Embroidery Tape TearAway
- OESD Alligator Clamps
- Perfect Embroidery Press Cloth
- 6" x 10" hoop
- Applique scissors
- Snips
- Tea lights and/or pixie lights (optional)
- Expert Point and Press Tool (optional)

# SUMMARY

12641-01



Requires 1 Design

12641-02



Requires 1 Design

12641-03



Requires 1 Design

12641-04



Requires 1 Design

12641-05



Requires 1 Design

12641-06




Requires 1 Design

12641-07




Requires 1 Design

12641-08



Requires 1 Design

12641-09



Requires 1 Design

12641-10



Requires 1 Design

12641-11



Requires 1 Design

12641-12



Requires 1 Design

12641-13



Requires 1 Design

# EMBROIDERY



## STEP 1

- The following applique instructions apply to all applique designs (FSA). See specific design instructions for details.
- Load machine and bobbin with the Isacord 0020 thread.
- Load design 12641-04, Haunted Back Wall FSA.
- Hoop one layer of AquaMesh WashAway with one layer of BadgeMaster in a hoop closest to the design size.



## STEP 2

- Stitch Color 1, Back Wall Fabric Placement.



## STEP 3

- Cut two pieces of prepared wall fabric slightly larger than the placement lines.
- Cover the placement lines with the prepared fabric. Tape in place as shown to secure.
- Return the hoop to the machine.





## STEP 4

- Stitch Color 2, Cut Line and Tackdown.
- Carefully remove the hoop from the machine, but not the project from the hoop.
- Trim excess fabric close to the placement line with sharp applique scissors.
- Return the hoop to the machine.




## STEP 5

- Stitch Color 3, Window Placement Stitch.
- Cut a piece of prepared fabric slightly larger than the window and position over the placement stitch. Tape to secure.
- Stitch Color 4, Cut Line and Tackdown
- Remove the hoop from the machine, but not the project from the hoop.
- Trim excess fabric close to the placement line with sharp applique scissors.
- Return the hoop to the machine.



## STEP 6

- Stitch Color 5, Shutters and Door Fabric Placement Stitch.
- Cut three pieces of prepared fabric slightly larger than the placement line and position it over the placement lines. Tape to secure.
- Stitch Color 6, Cut Line and Tackdown.
- Carefully remove the hoop from the machine, but not the project from the hoop.
- Trim away excess fabric, close to the stitching line.
- Return the hoop to the machine.




## STEP 7

- Stitch Color 7, Lace and Cover Stitch.
- Change upper thread to either grey or glow-in-the-dark thread.
- Stitch Color 8, Grey Linework.
- Remove the project from the hoop and trim away excess stabilizer to 1/4" - 1/2" from design.
- Repeat these instructions for all FSA pieces, except 12641-06 and 12641-09.



## STEP 1 Optional Instructions for Designs 06 and 09

- Stitch Color 1, Foundation Placement Stitch.



## STEP 2

- Place a piece of prepared wall fabric over the placement line.
- Tape to secure.



## STEP 3

- Stitch Color 2, Cut Line and Tackdown.




## STEP 4

- Carefully remove the hoop from the machine, but not the project from the hoop. Trim close to the tackdown stitching around the outer edge with applique scissors.
- Cut a slit in the hole then trim through all layers (including hooped stabilizers) close to the stitching as shown.



## STEP 5

- Cover the opening with a scrap of AquaMesh Plus, AquaMesh or BadgeMaster.
- Use 505 Temporary Spray Adhesive or a water-soluble glue stick to secure, if necessary. If using tape, make sure the tape is out of the way of the cover stitching.
- 



## STEP 6

- Return the hoop to the machine. Stitch the remaining colors).
- Remove completed design from the hoop and trim away excess stabilizer to 1/4"-1/2" from design.





# ASSEMBLY



## STEP 1

- Rinse all pieces in warm running water. For best results, rinse until the pieces are just slightly sticky.
- Lay the pieces right side down on a rack or smooth surface (i.e. parchment paper, wax paper) to dry completely.



## STEP 2

- Press pieces, right side down, on a Perfect Embroidery Pressing Cloth. Allow the pieces to cool in place.
- For pieces 02 (Haunted Eaves) and 08 (Haunted Chimney) also press the crease(s) where the pieces fold at the hinges.



## STEP 3

- Insert piece 02 Haunted Eaves into 01 Haunted Front Wall by pulling the buttonettes on the Eaves through the eyelets above the Front Wall door as shown.
- If the eyelets need a bit of stretching, insert the small hole end of the Expert Point and Press Tool and gently stretch the opening.



# ASSEMBLY



## STEP 4

- Attach pieces 01, 03, 04 and 05 together in a row by pulling the buttonettes through the corresponding eyelets on the adjacent piece as shown.



## STEP 5

- Attach piece 01 to piece 05.



## STEP 6

- Pull the top eyelet on piece 08 through the eyelet on the opposite side to create the chimney.



# ASSEMBLY



## STEP 7

- Pull the four buttonettes on the bottom of piece 08 (Chimney) through the eyelets in piece 06 (Roof 1) as shown.



## STEP 8

- Attach piece 06 to piece 07 (Roof 2) as shown.



## STEP 9

- Attach each side of the roof to the house structure as shown.




# ASSEMBLY



## STEP 10

- Attach each side of the foundation to the house structure as shown.




## STEP 11

- Pull the buttonettes on piece 11 (Tree Stand) through the eyelets on piece 10 (Tree).









## STEP 12

- Pull the buttonettes on piece 13 (Fence Stand) through the eyelets on piece 12 (Fence).







# APPLIQUE PATTERNS






# APPLIQUE PATTERNS



# APPLIQUE PATTERNS






# APPLIQUE PATTERNS







# APPLIQUE PATTERNS




# MIRRORED PATTERNS



# MIRRORED PATTERNS





# MIRRORED PATTERNS








# MIRRORED PATTERNS



# MIRRORED PATTERNS



## General Freestanding Lace Guidelines

### Supplies:

#### Embroidery Thread:

- Use the same embroidery thread in the bobbin as the needle.

#### Needles:

- Use an Organ 80/12 Titanium needle for extended needle life.

#### Stabilizer:

- Use OESD AquaMesh stabilizer.

### Handy Hints:

#### For Stiffer Lace:

- DO NOT rinse away all of the stabilizer for a “stiffer” lace. Note that the thread may appear a shade darker if stabilizer is not removed completely.
- If you happen to wash too much out, easily re-stiffen by diluting some stabilizer scraps in water and dipping the item in the solution.

#### For Very Soft Lace:

- Cut away excess stabilizer. Remove remaining stabilizer by rinsing under warm running water until all traces of the stabilizer are gone. **NOTE:** If lace should become too limp to work with, dissolve stabilizer scraps in warm water and apply to the lace.

#### Drying Lace:

- The lace looks best when left to dry completely. Lay lace piece with right side down to dry. This will minimize the tendency for the lace to curl. Be sure to flatten the piece out entirely and allow ample time to dry.

### General Instructions


1. Hoop two layers of OESD AquaMesh Stabilizer.
2. Attach the hoop to the machine and select the design of your choice.
3. Stitch the design.
4. Remove the hoop from the machine and the design from the hoop. Trim excess stabilizer from the design.
5. Rinse away remaining stabilizer and allow it to dry.

### Handy Hints:

#### For 3D Lace Projects:

- If item becomes too limp to work with, iron the lace pieces on the wrong side while applying spray starch. After ironing, spray again with starch and allow to dry completely. This will stiffen the lace pieces nicely and aid in construction.
- A pair of tweezers, hemostats, stiletto or a tiny crochet hook can be extremely helpful when inserting the buttonettes into the eyelets. (Please see **Diagram 1** for explanation of “buttonette” and “eyelet”.)
- Insert the tip of the alligator clamps, tweezers, hemostats or crochet hook into the eyelet, grasp the buttonette and pull through the eyelet. Or a stiletto could be used to push the buttonette through the eyelet.

Diagram 1





# FREESTANDING HAUNTED MANSION



1

Design

Fits hoop sizes 6" x 10" and larger



# THREAD LIST



## Isacord Thread Colors

- 0020 Black
- 0108 Cobblestone
- 0150 Mystik Grey

## DESIGNS

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

### \*Fabric Required




### 12830-01 Tower Wall 1 FSA

Size Inches:	Size mm:	Stitch Count:
8.35 X 2.82 in.	212.1 X 71.6 mm	16589 St.

- 1. Black Fabric Placement Stitch..... 0020
- 2. Cut Line and Tackdown ..... 0020
- 3. Lace and Cover Stitch ..... 0020

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**



### 12830-02 Tower Wall 2 FSA

Size Inches:                      Size mm:                      Stitch Count:  
**8.35 X 2.05 in.    212.1 X 52.1 mm    18770 St.**

- 1. Black Fabric Placement Stitch..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Gray Linework ..... 0108
- 4. Lace and Cover Stitch ..... 0020

**\*Fabric Required**




### 12830-03 Tower Wall 3 FSA

Size Inches:                      Size mm:                      Stitch Count:  
**8.36 X 2.67 in.    212.3 X 67.8 mm    25700 St.**

- 1. Black Fabric Placement Stitch..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Green Fabric Placement Stitch ..... 0108
- 4. Cut Line and Tackdown ..... 0108
- 5. Gray Linework ..... 0108
- 6. Window Lace ..... 0150
- 7. Lace and Cover Stitch ..... 0020

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**




### 12830-04 Tower Wall 4 FSA

Size Inches:                      Size mm:                      Stitch Count:  
**8.38 X 4.14 in. 212.9 X 105.2 mm 36424 St.**

- 1. Black Fabric Placement Stitch..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Black Fabric Placement Stitch..... 0108
- 4. Cut Line and Tackdown ..... 0108
- 5. Gray Linework ..... 0108
- 6. Lace and Cover Stitch ..... 0020

**\*Fabric Required**



### 12830-05 Back Wall 1 FSA

Size Inches:                      Size mm:                      Stitch Count:  
**5.70 X 4.87 in. 144.8 X 123.7 mm 21256 St.**

- 1. Purple Fabric Placement Stitch ..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Black Fabric Placement Stitch..... 0108
- 4. Cut Line and Tackdown ..... 0108
- 5. Gray Linework and Buttonette..... 0108
- 6. Window Detail ..... 0150
- 7. Lace and Cover Stitch ..... 0020

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**




### 12830-06 Side Wall 1 FSA

Size Inches:                      Size mm:                      Stitch Count:  
**7.60 X 3.56 in. 193.0 X 90.4 mm 24581 St.**

- 1. Orange Fabric Placement Stitch ..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Gray Linework ..... 0108
- 4. Window Detail ..... 0150
- 5. Lace and Cover Stitch ..... 0020

**\*Fabric Required**



### 12830-07 Front Wall 1 FSA

Size Inches:                      Size mm:                      Stitch Count:  
**4.85 X 3.23 in. 123.2 X 82.0 mm 15223 St.**

- 1. Purple Fabric Placement Stitch ..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Gray Linework and Buttonette ..... 0108
- 4. Window Detail ..... 0150
- 5. Lace and Cover Stitch ..... 0020



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**



### 12830-08 Front Wall 2 FSA

Size Inches:                      Size mm:                      Stitch Count:  
**7.11 X 3.43 in. 180.6 X 87.1 mm 20766 St.**

- 1. Orange Fabric Placement Stitch ..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Gray Linework ..... 0108
- 4. Lace and Cover Stitch ..... 0020

**\*Fabric Required**



### 12830-09 Side Wall 2 FSA

Size Inches:                      Size mm:                      Stitch Count:  
**3.48 X 2.34 in. 88.4 X 59.4 mm 9560 St.**

- 1. Black Fabric Placement Stitch..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Gray Linework and Buttonette..... 0108
- 4. Lace and Cover Stitch ..... 0020

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**




## 12830-10 Back Wall 2 FSA

Size Inches:	Size mm:	Stitch Count:
<b>7.11 X 3.43 in.</b>	<b>180.6 X 87.1 mm</b>	<b>21169 St.</b>

- 1. Orange Fabric Placement Stitch ..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Gray Linework ..... 0108
- 4. Lace and Cover Stitch ..... 0020

**\*Fabric Required**



## 12830-11 Front Roof 1 FSA

Size Inches:	Size mm:	Stitch Count:
<b>6.60 X 4.02 in.</b>	<b>167.6 X 102.1 mm</b>	<b>40531 St.</b>

- 1. Black Fabric Placement Stitch..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Gray Roof Detail ..... 0108
- 4. Lace and Cover Stitch ..... 0020

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**



### 12830-12 Roof Top FSA

Size Inches:                      Size mm:                      Stitch Count:  
**6.40 X 1.58 in. 162.6 X 40.1 mm 12855 St.**

- 1. Black Fabric Placement Stitch..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Gray Roof Detail..... 0108
- 4. Lace and Cover Stitch ..... 0020

**\*Fabric Required**



### 12830-13 Back Roof FSA

Size Inches:                      Size mm:                      Stitch Count:  
**3.83 X 3.75 in. 97.3 X 95.3 mm 22900 St.**

- 1. Black Fabric Placement Stitch..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Gray Roof Detail..... 0108
- 4. Lace and Cover Stitch ..... 0020

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.




## 12830-14 Boards FSL

Size Inches:                      Size mm:                      Stitch Count:  
**4.08 X 2.32 in. 103.6 X 58.9 mm 10037 St.**

- 1. Single Color Design..... 0020

**\*Fabric Required**



## 12830-15 Front Door Walls FSA


Size Inches:                      Size mm:                      Stitch Count:  
**5.62 X 5.36 in. 142.7 X 136.1 mm 27829 St.**

- 1. Purple Fabric Placement Stitch ..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Black Fabric Placement Stitch..... 0108
- 4. Cut Line and Tackdown ..... 0108
- 5. Green Fabric Placement Stitch ..... 0108
- 6. Cut Line and Tackdown ..... 0108
- 7. Orange Fabric Placement Stitch ..... 0108
- 8. Cut Line and Tackdown ..... 0108
- 9. Gray Linework ..... 0108
- 10. Window Detail ..... 0150
- 11. Lace and Cover Stitch ..... 0020



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**




### 12830-16 Front Door Roof FSA

Size Inches:                      Size mm:                      Stitch Count:  
**6.16 X 2.93 in. 156.5 X 74.4 mm 24645 St.**

- 1. Black Fabric Placement Stitch..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Black Fabric Placement Stitch..... 0108
- 4. Cut Line and Tackdown ..... 0108
- 5. Gray Roof Detail..... 0108
- 6. Black..... 0020

**\*Fabric Required**



### 12830-17 Side Roof FSA

Size Inches:                      Size mm:                      Stitch Count:  
**7.71 X 3.37 in. 195.8 X 85.6 mm 40734 St.**


- 1. Black Fabric Placement Stitch..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Black Fabric Placement Stitch..... 0108
- 4. Cut Line and Tackdown ..... 0108
- 5. Gray Roof Detail..... 0108
- 6. Lace and Cover Stitch ..... 0020

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.


## 12830-18 Tower Topper FSL

Size Inches:                      Size mm:                      Stitch Count:  
 2.42 X 3.00 in.    61.5 X 76.2 mm    17404 St.

- 1. Single Color Design..... 0020



**\*Fabric Required**




## 12830-19 Cupola Walls FSA

Size Inches:                      Size mm:                      Stitch Count:  
 7.25 X 4.59 in.    184.2 X 116.6 mm    32571 St.

- 1. Orange Fabric Placement Stitch ..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Black Fabric Placement Stitch..... 0108
- 4. Cut Line and Tackdown ..... 0108
- 5. Purple Fabric Placement Stitch ..... 0108
- 6. Cut Line and Tackdown ..... 0108
- 7. Green Fabric Placement Stitch ..... 0108
- 8. Cut Line and Tackdown ..... 0108
- 9. Gray Buttonettes and Linework ..... 0108
- 10. Window Detail ..... 0150
- 11. Lace and Cover Stitch ..... 0020

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**




## 12830-20 Cupola Roof FSA

Size Inches:                      Size mm:                      Stitch Count:  
**5.71 X 5.28 in. 145.0 X 134.1 mm 27782 St.**

- 1. Black Fabric Placement Stitch..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Black Fabric Placement Stitch..... 0108
- 4. Cut Line and Tackdown ..... 0108
- 5. Black Fabric Placement Stitch..... 0108
- 6. Cut Line and Tackdown ..... 0108
- 7. Black Fabric Placement Stitch..... 0108
- 8. Cut Line and Tackdown ..... 0108
- 9. Gray Roof Detail..... 0108
- 10. Lace and Cover Stitch ..... 0020

**\*Fabric Required**




## 12830-21 Floors FSA

Size Inches:                      Size mm:                      Stitch Count:  
**6.13 X 4.93 in. 155.7 X 125.2 mm 14431 St.**

- 1. Black Fabric Placement Stitch..... 0020
- 2. Cut Line and Tackdown ..... 0020
- 3. Black Fabric Placement Stitch..... 0020
- 4. Cut Line and Tackdown ..... 0020
- 5. Lace and Cover Stitch ..... 0020

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.


## 12830-22 Iron Cresting FSL



Size Inches:                      Size mm:                      Stitch Count:  
**6.24 X 4.69 in. 158.5 X 119.1 mm 41893 St.**

- 1. Single Color Design..... 0020

**\*Fabric Required**



## 12830-23 Tealight Floors FSA

Size Inches:                      Size mm:                      Stitch Count:  
**6.13 X 4.87 in. 155.7 X 123.7 mm 17551 St.**

- 1. Black Fabric Placement Stitch..... 0020
- 2. Cut Line and Tackdown ..... 0020
- 3. Black Fabric Placement Stitch..... 0020
- 4. Cut Line and Tackdown ..... 0020
- 5. Lace and Cover Stitch ..... 0020



## Stabilizer

- AquaMesh WashAway
- BadgeMaster WashAway
- StabilStick CutAway

## Supplies

- Alligator clamps, tweezers, hemostats, stiletto or a tiny crochet hook
- Expert Embroidery Tape TearAway
- Perfect Embroidery Press Cloth (recommended)
- Optional: Button Clips

## Isacord

- 0020
- 0108
- 0150
- Note: Match bobbin thread to upper thread

## Fabric



- 1 fat quarter each of the following colors in cotton
  - Black
  - Gray (**Note:** NOT required, but used in project instructions for roof sections)
  - Green
  - Orange
  - Purple

## NOTE

- The project includes freestanding applique designs and freestanding lace designs. All applique designs are stitched the same as shown in the instructions. All designs are stitched with matching thread in the top and bobbin, with one piece of AquaMesh and one piece of BadgeMaster in the hoop.

## STEP 1

- For each applique, cut a piece of fabric slightly larger than the placement stitch. Peel the paper from the StabilStick and apply 2 pieces to the back of each applique piece. The stabilizer acts as a stiffener for the design and stays in the project.




## STEP 2

- Hoop 1 piece of AquaMesh and 1 piece of BadgeMaster for each design.




## STEP 3

- Stitch Color 1, the Placement Stitch.
- Prep the applique fabric as described above.




## STEP 4

- Place the fabric right side up, over the placement stitch, covering entirely. Tape in place.




## STEP 5

- Stitch Color 2, the Tackdown and Cut line.




## STEP 6

- Remove the hoop from the machine, but do NOT remove the project from the hoop. Trim the excess fabric as close to the tackdown as possible, without cutting the stitches.




## STEP 6 Continued

- Return the hoop to the machine and stitch remaining colors, following the thread chart.
- **Note:** Remember to change the bobbin to match the upper thread colors.



## STEP 7

- When design is complete, remove the project from the hoop and trim the stabilizer about a ½" from the stitches.





# EMBROIDERY



## STEP 8

- Rinse in warm running water until project is slightly sticky.



## STEP 9

- Lay face down and let dry.
- Note: Do not place on a paper towel or towel with loops as they tend to stick to the design. Parchment paper or a cooling rack works well.



## STEP 10

- Press face down on a Perfect Embroidery Pressing Cloth, if needed.




## NOTE

- There is some sewing with this project. An open toe foot is helpful when sewing together. Use a zigzag stitch or serpentine stitch to sew together. Suggested settings: length- 1.5 and width- 4.0.

## STEP 1 SECTION 1

- Sew together designs 12830-01, 12830-02, 12830-03 and 12830-04 as shown.



## STEP 2

- Place 12830-01 and 12830-02 right sides facing up, lining up as shown.




# ASSEMBLY



## STEP 3

- Using a zigzag stitch, sew the two pieces together, backstitching at the beginning and end. Continue sewing the two remaining pieces to the first two.



## STEP 4 SECTION 2

- Using two of the lace boards from 12830-14, sew one to each of the windows in designs 05 and 07.



## STEP 5

- Sew designs 12830-05, 12830-06 and 12830-07 together as shown in the photos.





## STEP 6 SECTION 3

- Sew the remaining 2 lace boards from 12830-14 over the window in 12830-08.




## STEP 7

- Sew designs 12830-08, 12830-09 and 12830-10 together as shown in the photos.



## STEP 8 SECTION 4

- Sew designs 12830-11, 12830-12 and 12830-13 together as shown.





## STEP 9 SECTION 5

- Designs 12830-15(front door) and 12830-16(roof)




## STEP 10

- Bend the three sections of 12830-15 as shown.




## STEP 11

- Insert the alligator clamps through the eyelet in the roof, grab the corresponding buttonette and pull through. Repeat for the other buttonette.




## STEP 12

- Attach Section 5 to Section 1, inserting the tabs into the corresponding slots, as shown.




## STEP 13

- Bend Section 5 so that the buttonettes line up with the eyelets. Pull the 4 buttonettes through the eyelets as shown. This forms a tower. Set aside.



## STEP 14

- Section 2 and Section 4 (roof) will be connected next. Bend each section as shown.



## STEP 15

- Attach each buttonette on Section 2 to the eyelets in the roof.



## STEP 16

- Section 3 and design 12830-13 (roof) .



## STEP 17

- Bend the 3 pieces of section 3.






## STEP 18

- Bend the roof. Match the eyelets and buttonettes. Pull each buttonette through the corresponding eyelet, using button clips to temporarily hold them in place, as needed.



## STEP 19

- Attach Section 2 to the left side of Section 1, inserting the tabs into the slots and buttonettes into the eyelets, as shown.



## STEP 20


- Attach Section 3 to the right side of Section 1, inserting the tabs into the slots.
- **Note:** After putting the tabs of one side into the slots, twist them slightly to help them stay in place, or use Button clips to temporarily hold them.





## STEP 21

- Attach the two pieces of 12830-23 to the bottom of the mansion, inserting the buttonettes into the corresponding eyelets



## STEP 22

- Attach design 12830-18 to the top of the tower pulling the 4 buttonettes through the eyelets.




## STEP 23

- Cupola and Roof.



## STEP 24

- Bend design 12830-19 and pull the 2 buttonettes through the corresponding eyelets.




## STEP 25

- Starting at the top of the roof (design 12830-20), pull buttonettes through each eyelet.




## STEP 26

- Attach the roof to the cupola by pulling the buttonettes through the eyelets in the roof.



## STEP 27

- Attach the completed cupola to the center of the roof by inserting the tabs into design 12830-18.




## STEP 28

- Design 12830-22 is the Iron Cresting that attaches to the top of the roof.



## STEP 29

- Bend the larger one and attach to the left side of the mansion by inserting the tabs into the roof.






# ASSEMBLY



## STEP 30

- Bend the smaller one and insert the tabs into the slots in the right side roof.




## STEP 31

- The haunted mansion is now complete!









# APPLIQUE PATTERNS





# APPLIQUE PATTERNS






# APPLIQUE PATTERNS














# APPLIQUE PATTERNS










# APPLIQUE PATTERNS




# APPLIQUE PATTERNS






# APPLIQUE PATTERNS










# APPLIQUE PATTERNS



# MIRRORED PATTERNS





# MIRRORED PATTERNS












# MIRRORED PATTERNS






# MIRRORED PATTERNS



# MIRRORED PATTERNS








# MIRRORED PATTERNS











# MIRRORED PATTERNS






# MIRRORED PATTERNS





# MIRRORED PATTERNS





## General Freestanding Lace Guidelines

### Supplies:

#### Embroidery Thread:

- Use the same embroidery thread in the bobbin as the needle.

#### Needles:

- Use an Organ 80/12 Titanium needle for extended needle life.

#### Stabilizer:

- Use OESD AquaMesh stabilizer.

### Handy Hints:

#### For Stiffer Lace:

- DO NOT rinse away all of the stabilizer for a “stiffer” lace. Note that the thread may appear a shade darker if stabilizer is not removed completely.
- If you happen to wash too much out, easily re-stiffen by diluting some stabilizer scraps in water and dipping the item in the solution.

#### For Very Soft Lace:

- Cut away excess stabilizer. Remove remaining stabilizer by rinsing under warm running water until all traces of the stabilizer are gone. **NOTE:** If lace should become too limp to work with, dissolve stabilizer scraps in warm water and apply to the lace.

#### Drying Lace:

- The lace looks best when left to dry completely. Lay lace piece with right side down to dry. This will minimize the tendency for the lace to curl. Be sure to flatten the piece out entirely and allow ample time to dry.

### General Instructions


1. Hoop two layers of OESD AquaMesh Stabilizer.
2. Attach the hoop to the machine and select the design of your choice.
3. Stitch the design.
4. Remove the hoop from the machine and the design from the hoop. Trim excess stabilizer from the design.
5. Rinse away remaining stabilizer and allow it to dry.

### Handy Hints:

#### For 3D Lace Projects:

- If item becomes too limp to work with, iron the lace pieces on the wrong side while applying spray starch. After ironing, spray again with starch and allow to dry completely. This will stiffen the lace pieces nicely and aid in construction.
- A pair of tweezers, hemostats, stiletto or a tiny crochet hook can be extremely helpful when inserting the buttonettes into the eyelets. (Please see **Diagram 1** for explanation of “buttonette” and “eyelet”.)
- Insert the tip of the alligator clamps, tweezers, hemostats or crochet hook into the eyelet, grasp the buttonette and pull through the eyelet. Or a stiletto could be used to push the buttonette through the eyelet.

Diagram 1





# FREESTANDING MIDNIGHT MANOR



**1**

**Design**

**Fits hoop sizes 6" x 10" and larger**



# THREAD LIST



## Isacord Thread Colors


0015 White  
0108 Cobblestone  
0145 Skylight  
1260 ISA TEXTLIGHT  
4174 Charcoal

**\*Project instructions included after design list**

## DESIGNS

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**




### 12872-01 Front Wall FSA

Size Inches:                      Size mm:                      Stitch Count:  
**7.38 X 5.01 in. 187.4 X 127.1 mm 53213 St.**

■	1. Light Grey Fabric Placement Stitch.....	4174
■	2. Cut Line and Tackdown .....	4174
■	3. Grey Fabric Placement Stitch.....	4174
■	4. Cut Line and Tackdown .....	4174
■	5. Grey Detail .....	4174
□	6. Windows.....	0015
■	7. Door Detail .....	0145
■	8. Curtains and Grey Detail.....	0108
■	9. Lace and Cover Stitch .....	4174
□	10. Glow Detail .....	1260

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**




**12872-02 Side Wall 1 FSA**

Size Inches:                      Size mm:                      Stitch Count:  
**7.37 X 3.74 in. 187.2 X 94.9 mm 38430 St.**

- 1. Light Grey Fabric Placement Stitch..... 4174
- 2. Cut Line and Tackdown ..... 4174
- 3. Dark Grey Detail..... 4174
- 4. Light Grey Detail..... 0108
- 5. Windows..... 0015
- 6. Curtains and Window Detail ..... 0108
- 7. Lace and Cover Stitch ..... 4174
- 8. Glow Detail ..... 1260

**\*Fabric Required**



**12872-03 Back Wall 1 FSA**

Size Inches:                      Size mm:                      Stitch Count:  
**7.36 X 4.13 in. 186.9 X 104.8 mm 34260 St.**

- 1. Light Grey Fabric Placement Stitch..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Light Grey Detail..... 0108
- 4. Windows..... 0015
- 5. Window Detail ..... 0108
- 6. Lace and Cover Stitch ..... 4174
- 7. Glow ..... 1260



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**




**12872-04 Back Wall 2 FSA**

Size Inches:                      Size mm:                      Stitch Count:  
**7.36 X 2.27 in. 187.1 X 57.7 mm 21435 St.**





-  1. Light Grey Fabric Placement Stitch..... 0015
-  2. Cut Line and Tackdown ..... 0015
-  3. Grey Fabric Placement Stitch..... 0015
-  4. Cut Line and Tackdown ..... 0015
-  5. Window..... 0015
-  6. Light Grey Detail..... 0145
-  7. Grey Detail ..... 0108
-  8. Lace and Cover Stitch ..... 4174
-  9. Glow Detail ..... 1260

**\*Fabric Required**




**12872-05 Side Wall 2 FSA**

Size Inches:                      Size mm:                      Stitch Count:  
**7.37 X 3.11 in. 187.1 X 79.0 mm 26211 St.**

-  1. Light Grey Fabric Placement Stitch..... 0015
-  2. Cut Line and Tackdown ..... 0015
-  3. Window..... 0015
-  4. Curtain and Grey Detail..... 0108
-  5. Lace and Cover Stitch ..... 4174
-  6. Glow Detail ..... 1260

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**




### 12872-06 Front Porch Walls FSA

Size Inches:                      Size mm:                      Stitch Count:  
**7.91 X 5.03 in. 200.9 X 127.8 mm 58120 St.**

- 1. Grey Fabric Placement Stitch..... 0145
- 2. Cut Line and Tackdown ..... 0145
- 3. Light Grey Detail..... 0145
- 4. Lace and Cover Stitch ..... 4174
- 5. Glow Detail ..... 1260

**\*Fabric Required**



### 12872-07 Front Porch FSA

Size Inches:                      Size mm:                      Stitch Count:  
**4.44 X 4.40 in. 112.9 X 111.7 mm 23042 St.**

- 1. Grey Fabric Placement Stitch..... 0145
- 2. Cut Line and Tackdown ..... 0145
- 3. Light Grey Detail..... 0145
- 4. Lace and Cover Stitch ..... 4174
- 5. Glow Detail ..... 1260

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**



### 12872-08 Front Porch Roof FSA

Size Inches:                      Size mm:                      Stitch Count:  
**5.91 X 3.15 in. 150.1 X 80.0 mm 24006 St.**

- 1. Dark Grey Fabric Placement Stitch ..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Grey Detail ..... 0108
- 4. Lace and Cover Stitch ..... 4174
- 5. Glow Detail ..... 1260

**\*Fabric Required**



### 12872-09 Tower Back Wall FSA

Size Inches:                      Size mm:                      Stitch Count:  
**8.50 X 2.68 in. 215.9 X 68.1 mm 24896 St.**

- 1. Grey Fabric Placement Stitch..... 0145
- 2. Cut Line and Tackdown ..... 0145
- 3. Light Grey Detail..... 0145
- 4. Lace and Cover Stitch ..... 4174
- 5. Glow Detail ..... 1260








Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**



### 12872-10 Tower Side Wall 1 FSA

Size Inches:                      Size mm:                      Stitch Count:  
**8.75 X 2.18 in. 222.2 X 55.3 mm 20503 St.**









-  1. Grey Fabric Placement Stitch..... 0015
-  2. Cut Line and Tackdown ..... 0015
-  3. Window..... 0015
-  4. Light Grey Detail..... 0145
-  5. Window Detail ..... 0108
-  6. Lace and Cover Stitch ..... 4174
-  7. Glow Detail ..... 1260

**\*Fabric Required**



### 12872-11 Tower Front Wall FSA


Size Inches:                      Size mm:                      Stitch Count:  
**8.75 X 2.52 in. 222.3 X 64.1 mm 27205 St.**

-  1. Grey Fabric Placement Stitch..... 0145
-  2. Cut Line and Tackdown ..... 0145
-  3. Light Grey Detail..... 0145
-  4. Dark Grey Detail..... 4174
-  5. Windows..... 0015
-  6. Curtains ..... 0108
-  7. Lace and Cover Stitch ..... 4174
-  8. Glow Detail ..... 1260



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**




### 12872-12 Tower Side Wall 2 FSA

Size Inches:                      Size mm:                      Stitch Count:  
**8.74 X 2.42 in. 222.0 X 61.5 mm 27662 St.**

- 1. Grey Fabric Placement Stitch..... 0145
- 2. Cut Line and Tackdown ..... 0145
- 3. Light Grey Detail..... 0145
- 4. Lace and Cover Stitch ..... 4174
- 5. Glow Detail ..... 1260

**\*Fabric Required**



### 12872-13 Tower Roof FSA

Size Inches:                      Size mm:                      Stitch Count:  
**6.44 X 5.45 in. 163.7 X 138.4 mm 30698 St.**

- 1. Dark Grey Fabric Placement Stitch..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Grey Detail ..... 0108
- 4. Lace and Cover Stitch ..... 4174
- 5. Glow Detail ..... 1260

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**




### 12872-14 Roof Top FSA

Size Inches:	Size mm:	Stitch Count:
<b>5.28 X 0.76 in.</b>	<b>134.1 X 19.3 mm</b>	<b>6192 St.</b>

- 1. Dark Grey Fabric Placement Stitch ..... 4174
- 2. Cut Line and Tackdown ..... 4174
- 3. Grey Detail and Cover Stitch ..... 4174
- 4. Glow Detail ..... 1260

**\*Fabric Required**




### 12872-15 Front Roof FSA

Size Inches:	Size mm:	Stitch Count:
<b>6.27 X 4.29 in.</b>	<b>159.2 X 108.9 mm</b>	<b>31526 St.</b>

- 1. Dark Grey Fabric Placement Stitch ..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Grey Detail ..... 0108
- 4. Cover Stitch ..... 4174
- 5. Glow Detail ..... 1260

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**




### 12872-16 Back Roof FSA

Size Inches:                      Size mm:                      Stitch Count:  
**6.78 X 4.29 in. 172.1 X 108.9 mm 29963 St.**

- 1. Dark Grey Fabric Placement Stitch ..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Grey Detail ..... 0108
- 4. Cover Stitch ..... 4174
- 5. Glow Detail ..... 1260

**\*Fabric Required**



### 12872-17 Side Roof 1 FSA


Size Inches:                      Size mm:                      Stitch Count:  
**3.86 X 4.39 in. 98.0 X 111.6 mm 12482 St.**

- 1. Dark Grey Fabric Placement Stitch ..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Grey Detail ..... 0108
- 4. Cover Stitch ..... 4174
- 5. Glow Detail ..... 1260

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**

**12872-18 Side Roof 2 FSA**




Size Inches:                      Size mm:                      Stitch Count:  
**3.86 X 2.97 in. 98.0 X 75.5 mm 9120 St.**

- 1. Dark Grey Fabric Placement Stitch ..... 0108
- 2. Cut Line and Tackdown ..... 0108
- 3. Grey Detail ..... 0108
- 4. Cover Stitch ..... 4174
- 5. Glow Detail ..... 1260

**\*Fabric Required**

**12872-19 Dormer Window FSA**




Size Inches:                      Size mm:                      Stitch Count:  
**6.49 X 4.90 in. 165.0 X 124.6 mm 23096 St.**

- 1. Roof Grey Fabric/Window Light Grey Fabric Placement Stitch ..... 0145
- 2. Cut Line and Tackdown ..... 0145
- 3. Grey Detail ..... 0145
- 4. Lace and Cover Stitch ..... 4174
- 5. Glow Detail ..... 1260
- 6. Window ..... 0015
- 7. Grey Detail ..... 0108
- 8. Lace and Cover Stitch ..... 4174
- 9. Glow Detail ..... 1260



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**




## 12872-20 Tealight Floor FSA

Size Inches:                      Size mm:                      Stitch Count:  
**6.44 X 4.23 in. 163.7 X 107.4 mm 12041 St.**

- 1. Grey Fabric Placement Stitch..... 0145
- 2. Cut Line and Tackdown ..... 0145
- 3. Grey Detail ..... 0145
- 4. Cover Stitch..... 4174

**\*Fabric Required**



## 12872-21 Tower Floor FSA

Size Inches:                      Size mm:                      Stitch Count:  
**2.69 X 2.36 in. 68.4 X 60.1 mm 3913 St.**

- 1. Grey Fabric Placement Stitch..... 0145
- 2. Cut Line and Tackdown ..... 0145
- 3. Grey Detail ..... 0145
- 4. Cover Stitch..... 4174

## Stabilizers

- OESD AquaMesh
- OESD BadgeMaster
- OESD StabilStick CutAway

## Fabrics/Textiles

- ¼ yard Light Grey Fabric
- ¼ yard Medium Grey Fabric
- ¼ yard Dark Grey Fabric
- Roof Variation: substitute Luxe Sparkle Vinyl by OESD in Black (1 roll) for Dark Gray Fabric.
- Note: Fabric sizes are estimates and may result in overage.

## Notions & Tools

- OESD Alligator Clamps
- OESD Expert Embroidery Tape WashAway
- OESD Perfect Punch Tool
- OESD Perfect Embroidery Press Cloth
- Optional: Button Clips


## Isacord Thread Colors

- Per thread chart
- Match bobbin thread to top thread.

# SUMMARY



12872-01



Requires 1 Design

12872-02



Requires 1 Design

12872-03




Requires 1 Design

12872-04




Requires 1 Design

12872-05




Requires 1 Design

12872-06




Requires 1 Design

12872-07



Requires 1 Design

12872-08



Requires 1 Design

12872-09



Requires 1 Design

12872-10




Requires 1 Design

12872-11




Requires 1 Design

12872-12



Requires 1 Design

12872-13



Requires 1 Design

12872-14



Requires 1 Design

12872-5




Requires 1 Design

12872-16



Requires 1 Design

12872-17




Requires 1 Design

12872-18




Requires 1 Design

12872-19




Requires 1 Design

12872-20



Requires 1 Design

12872-21



Requires 1 Design

# EMBROIDERY



## STEP 1

- Adhere two layers of StabilStick CutAway to the wrong side of all applique fabrics to provide stiffness to the finished structure.




## STEP 2

- Hoop one layer of AquaMesh and one layer of BadgeMaster in the hoop for all designs.



## STEP 3

- Load selected design into the machine.
- Design in the example is 12872-01.
- Thread the machine per the thread chart.
- Stitch Machine Step 1, Light Grey Fabric Placement Stitch.
- Note: Some thread colors in instructions have been changed or digitally enhanced for better visibility.





## STEP 4

- Remove the hoop from the machine, but NOT the project from the hoop.
- Lay the hoop on a flat surface.
- Cover the placement line completely with the prepared fabric.
- Tape in place to secure.




## STEP 5

- Return the hoop to the machine.
- Stitch Machine Step 2, Cut Line and Tackdown.




## STEP 6

- Remove the hoop from the machine, but NOT the project from the hoop.
- Trim the excess fabric as close to the cut line as possible. If the outermost stitches are cut, the inner stitches will still hold the applique in place.
- Tip: If the AquaMesh is cut or a hole is created while trimming the fabric, use Expert Embroidery Tape WashAway or AquaMesh Plus as a patch.




## STEP 7

- Return the hoop to the machine.
- Stitch Machine Step 3, Grey Fabric Placement Stitch.




## STEP 8

- Remove the hoop from the machine, but NOT the project from the hoop. Lay the hoop on a flat surface.
- Cover the placement line completely with the prepared fabric.
- Tape in place to secure.



## STEP 9

- Return the hoop to the machine.
- Stitch Machine Step 4, Cut Line and Tackdown.



## STEP 10

- Remove the hoop from the machine, but NOT the project from the hoop.
- Trim the excess fabric as close to the cut line as possible. If the outermost stitches are cut, the inner stitches will still hold the applique in place.



## STEP 11

- Return the hoop to the machine and stitch the remaining steps according to the thread chart.
- Remember to match the bobbin thread to the upper thread colors.



## STEP 12


- When design is complete, remove the project from the hoop and trim the stabilizer  $\frac{1}{4}$ "-  $\frac{1}{2}$ " outside the design.




## NOTE ROOF VARIATION WITH LUXE SPARKLE VINYL

- Roof units include 12872-08, 12872-13, 12872-14, 12872-15, 12872-16, 12872-17, 12872-18, 12872-19. Design 12872-19 includes two applique pieces, only the roof is Luxe Sparkle Vinyl.

12872-08



12872-13



12872-14




12872-15




12872-16




12872-17



12872-18



12872-19



## STEP 13

- Adhere two layers of StabilStick CutAway to the wrong side of Luxe Sparkle Vinyl to provide stiffness to the finished structure.






## STEP 14

- Hoop one layer of AquaMesh and one layer of BadgeMaster.



## STEP 15

- Load selected design into the machine.
- Example design is 12872-16.
- Place the hoop on the machine.
- Thread the machine per the thread chart.
- Stitch Machine Step 1, Dark Grey Fabric Placement Stitch.




## STEP 16

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Cover the placement line completely with the prepared fabric.
- Tape in place to secure.



## STEP 17

- Return the hoop to the machine.
- Stitch Machine Step 4, Cut Line and Tackdown.



## STEP 18

- Remove the hoop from the machine, but NOT the project from the hoop.
- Trim the excess fabric as close to the cut line stitching as possible.




## STEP 19

- Return the hoop to the machine and stitch the remaining machine steps per the thread chart.
- Match the bobbin thread to the upper thread colors.



## STEP 20

- When the design is complete, remove the project from the hoop and trim the stabilizer 1/4" - 1/2" outside the design.



# ASSEMBLY




## STEP 1

- Rinse each piece in warm running water until the design is only slightly sticky.
- Lay face down on a non-stick surface to dry. Parchment paper or a cooling rack work well. This prevents the piece from curling.
- Press each piece, right side down, on a Perfect Embroidery Press Cloth.



## STEP 2

- Insert the 3 mm attachment into the Perfect Punch Tool and punch holes in the eyelets indicated in the Punch tool guides located on pg. 33.






# ASSEMBLY



## STEP 3

- Line up wall pieces right side up 12872-01, 12872-02, 12872-03, 12872-04 and 12872-05 to connect.
- Load the sewing machine with matching thread in the top and bobbin. An open toe or edge stitch foot is helpful.
- Stitch together using a multi-step zigzag stitch (also known as a serpentine stitch). Back stitch at the beginning and end to secure. Trim thread tails.
- Fold and press to shape.




## STEP 4

- Line up tower pieces 12872-09, 12872-10, 12872-11 and 12872-12 to connect.
- Stitch together using a multi-step zigzag stitch right side up (also known as a serpentine stitch). Back stitch at the beginning and end to secure. Trim thread tails.
- Fold and press to shape.





## STEP 5

- Line up roof pieces, right side up, 12872-14, 12872-15, 12872-16, 12872-17 and 12872-18 to connect.
- Stitch together using a multi-step zigzag stitch (also known as a serpentine stitch). Back stitch at the beginning and end to secure. Trim thread tails.



## STEP 6

- Match the eyelets and buttonettes on tower roof 12872-13. Pull each buttonette through the corresponding eyelet.




# ASSEMBLY




## STEP 7

- Match the eyelets and buttonettes of the tower. Pull each buttonette through the corresponding eyelet.



## STEP 8

- Match the tower roof eyelets to the tower buttonettes. Pull each buttonette through the corresponding eyelet.



# ASSEMBLY



## STEP 9

- Match the front porch eyelets and buttonettes 12872-06, 12872-07, and 12872-08 . Pull each buttonette through the corresponding eyelet.



## STEP 10

- Insert the front porch tabs into the corresponding front wall slots.
- Note: After putting the tabs into the slots, twist them slightly to help them stay in place, or use Button Clips to temporarily hold them.





## STEP 11

- Insert the front wall tabs into the corresponding tower slots.
- Note: After putting the tabs into the slots, twist them slightly to help them stay in place.



## STEP 12

- Insert the side wall tabs into the corresponding tower slots.
- Note: After putting the tabs into the slots, twist them slightly to help them stay in place.





## STEP 13

- Match the dormer roof eyelets to the dormer window buttonettes 12872-19. Pull each buttonette through the corresponding eyelet.



## STEP 14

- Match the eyelets and buttonettes of the roof 12872-15, 12872-16, 12872-17 and 12872-18. Pull each buttonette through the corresponding eyelet.



## STEP 15

- Insert the dormer tabs into the corresponding roof slots.
- Note: After putting the tabs into the slots, twist them slightly to help them stay in place.



## STEP 16

- Match the roof eyelets to the wall buttonettes. Pull each buttonette through the corresponding eyelet.




# ASSEMBLY




## STEP 17

- Match the tower eyelets to the tower floor buttonettes 12872-21. Pull each buttonette through the corresponding eyelet.



## STEP 18

- Match the wall eyelets to the tealight floor buttonettes 12872-20. Pull each buttonette through the corresponding eyelet.






## STEP 19


- Freestanding Midnight Manor is now complete.




12872-08





12872-12




12872-19




 = 2 MM

 = 3 MM

 = 4 MM


## ATTENTION

When printing this document, any page scaling or page fitting options in your print dialog box must be turned OFF or set to NONE so that your files will print out at their actual size. Images not printed at actual size will not function as intended.



## TO SAVE PAPER


Only print the desired image by navigating to the image's page, go to File > Print and select "Current page" in the print dialog box. Repeat for each desired image.



# APPLIQUE PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.






# APPLIQUE PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# APPLIQUE PATTERNS





Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# APPLIQUE PATTERNS








Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# APPLIQUE PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.







# APPLIQUE PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.




12872-09



Cut Out

12872-10



Cut Out



12872-11

Cut Out

# APPLIQUE PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# APPLIQUE PATTERNS






Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# APPLIQUE PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.








# APPLIQUE PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# MIRRORED PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# MIRRORED PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# MIRRORED PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.








# MIRRORED PATTERNS








Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# MIRRORED PATTERNS






Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# MIRRORED PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# MIRRORED PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.







# MIRRORED PATTERNS








Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# MIRRORED PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# MIRRORED PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.





# FREESTANDING SPOOKY SHACK



1

Design

# THREAD LIST



## Isacord Thread Colors

0010 Silky White  
0176 Fog  
4174 Charcoal

**\* Project instructions included after design list.**

**Note: One spool of 1000 meter thread is adequate for the project unless otherwise noted.**

## Table of Contents

Designs.....	3
Collection Supplies.....	9
Summary .....	10
Embroidery .....	11
Assembly .....	15
Freestanding Lace Guide.....	25
Punch Tool Guide.....	26
Applique Patterns.....	28
Mirrored Patterns.....	32



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**

**12902-01 Side Wall 1 FSA**




Size Inches:                      Size mm:                      Stitch Count:  
**4.05 X 4.33 in.    103.0 X 109.9 mm    19360 St.**

- 1. Gray Front/Black Back Fabric Placement Stitch .. 0176
- 2. Cut Line and Tackdown ..... 0176
- 3. Light Gray Detail..... 0176
- 4. Webs ..... 0010
- 5. Cover Stitch and Black Detail ..... 4174

**\*Fabric Required**

**12902-02 Front Wall FSA**



Size Inches:                      Size mm:                      Stitch Count:  
**6.74 X 5.56 in.    171.1 X 141.4 mm    34520 St.**

- 1. Gray Front/Black Back Fabric Placement Stitch .. 0176
- 2. Cut Line and Tackdown ..... 0176
- 3. Light Gray Detail..... 0176
- 4. Webs ..... 0010
- 5. Cover Stitch and Black Detail ..... 4174

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**

### 12902-03 Side Wall 2 FSA



Size Inches:	Size mm:	Stitch Count:
4.41 X 4.14 in.	112.1 X 105.1 mm	19721 St.

- 1. Gray Front/Black Back Fabric Placement Stitch .. 0176
- 2. Cut Line and Tackdown ..... 0176
- 3. Light Gray Detail..... 0176
- 4. Cover Stitch and Black Detail..... 4174

**\*Fabric Required**

### 12902-04 Back Wall FSA



Size Inches:	Size mm:	Stitch Count:
6.73 X 5.49 in.	171.0 X 139.6 mm	28737 St.

- 1. Gray Front/Black Back Fabric Placement Stitch .. 0176
- 2. Cut Line and Tackdown ..... 0176
- 3. Light Gray Detail..... 0176
- 4. Cover Stitch and Black Detail..... 4174

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

### 12902-05 Window Boards FSL

Size Inches:	Size mm:	Stitch Count:
2.42 X 2.06 in.	61.5 X 52.4 mm	4552 St.

- 1. Single Color Design..... 4174




#### \*Fabric Required

### 12902-06 Front Porch FSA

Size Inches:	Size mm:	Stitch Count:
5.32 X 3.42 in.	135.2 X 86.7 mm	21361 St.

- 1. Gray Front/Black Back Fabric Placement Stitch .. 0176
- 2. Cut Line and Tackdown ..... 0176
- 3. Light Gray Detail..... 0176
- 4. Cover Stitch and Black Detail..... 4174






Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**

**12902-07 Front Porch Roof FSA**

Size Inches:	Size mm:	Stitch Count:
4.73 X 3.41 in.	120.1 X 86.6 mm	13117 St.



- 1. Gray Front/Black Back Fabric Placement Stitch .. 0176
- 2. Cut Line and Tackdown ..... 0176
- 3. Light Gray Detail..... 0176
- 4. Cover Stitch and Black Detail..... 4174

**\*Fabric Required**

**12902-08 Front Porch Pillars FSA**

Size Inches:	Size mm:	Stitch Count:
6.65 X 3.69 in.	169.0 X 93.6 mm	15483 St.




- 1. Gray Front/Black Back Fabric Placement Stitch .. 4174
- 2. Cut Line and Tackdown ..... 4174
- 3. Cover Stitch and Black Detail..... 4174

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

**\*Fabric Required**

**12902-09 Roof 1 FSA**



Size Inches:                      Size mm:                      Stitch Count:  
**5.57 X 4.85 in.    141.4 X 123.2 mm    19900 St.**

- 1. Gray Front/Black Back Fabric Placement Stitch .. 0176
- 2. Cut Line and Tackdown ..... 0176
- 3. Light Gray Detail..... 0176
- 4. Webs ..... 0010
- 5. Cover Stitch and Black Detail..... 4174

**\*Fabric Required**

**12902-10 Roof 2 FSA**



Size Inches:                      Size mm:                      Stitch Count:  
**5.62 X 4.57 in.    142.6 X 116.2 mm    20237 St.**

- 1. Gray Front/Black Back Fabric Placement Stitch .. 0176
- 2. Cut Line and Tackdown ..... 0176
- 3. Light Gray Detail..... 0176
- 4. Webs ..... 0010
- 5. Cover Stitch and Black Detail..... 4174



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

## 12902-11 Roof Spider Webs FSL




Size Inches:	Size mm:	Stitch Count:
4.88 X 3.78 in.	123.8 X 96.0 mm	16044 St.

- 1. Buttonettes ..... 4174
- 2. Webs ..... 0010

**\*Fabric Required**

## 12902-12 Floor FSA



Size Inches:	Size mm:	Stitch Count:
5.35 X 4.63 in.	135.8 X 117.7 mm	16033 St.

- 1. Gray Front/Black Back Fabric Placement Stitch .. 0176
- 2. Cut Line and Tackdown ..... 0176
- 3. Light Gray Detail..... 0176
- 4. Cover Stitch and Black Detail..... 4174

## Stabilizers

- OESD AquaMesh WashAway
- OESD BadgeMaster WashAway
- OESD StabilStick CutAway

## Fabrics/Textiles

GRAY FRONT FABRIC	USED FOR
Gray quilter's cotton (2) 6 ½" x 8" Gray quilter's cotton (2) 5" x 5" Gray quilter's cotton (1) 2 ½" x 5 ½" Gray quilter's cotton (1) 3" x 6" Gray quilter's cotton (1) 4 ½" x 4 ½" Gray quilter's cotton (3) 6" x 7"	12902-02 & 04 Shack Outside Fabric 12902-01 & 03 Shack Outside Fabric 12902-06 Shack Outside Fabric 12902-07 Shack Outside Fabric 12902-08 Shack Outside Fabric 12902-09, 10 & 12 Shack Outside Fabric
BLACK FRONT FABRIC	USED FOR
Black quilter's cotton (2) 6 ½" x 8" Black quilter's cotton (2) 5" x 5" Black quilter's cotton (1) 2 ½" x 5 ½" Black quilter's cotton (1) 3" x 6" Black quilter's cotton (1) 4 ½" x 4 ½" Black quilter's cotton (3) 6" x 7"	12902-02 & 04 Shack Inner Fabric 12902-01 & 03 Shack Inner Fabric 12902-06 Shack Inner Fabric 12902-07 Shack Inner Fabric 12902-08 Shack Inner Fabric 12902-09, 10 & 12 Shack Inner Fabric

Note: Fabric sizes are estimates and may result in overage.

## Notions & Tools

- OESD Alligator Clamps
- OESD Button Clips
- Expert Embroidery Tape WashAway
- OESD Perfect Punch Tool
- OESD Perfect Embroidery Press Cloth
- Embroidery Needle Sharp 75/11
- Craft Knife

## Isacord Thread Colors

- Per thread chart
- Match the bobbin thread to the upper thread.

# SUMMARY




Completed Size: 7 1/2" H x 6 1/2" W x 6 1/2" D

12902-01



Requires 1 Design

12902-02



Requires 1 Design

12902-03




Requires 1 Design

12902-04




Requires 1 Design

12902-05




Requires 1 Design

12902-06



Requires 1 Design

12902-07



Requires 1 Design

12902-08



Requires 1 Design

12902-09




Requires 1 Design

12902-10




Requires 1 Design

12902-11



Requires 1 Design

12902-12



Requires 1 Design

## Notes

The freestanding applique instructions, included in the collection, are general instructions. For demonstration purposes, a sample design that best demonstrates the technique is shown.


Fabric and thread requirements will vary by design, but the general technique is the same.

All designs are stitched with matching thread, top and bobbin.

Note: Some thread colors in instructions have been changed or digitally enhanced for better visibility.

## STEP 1

- Hoop one layer of AquaMesh and one layer of BadgeMaster for all designs.



## Step 2

- Adhere one layer of StabilStick CutAway to the wrong side of all applique fabrics, to provide stiffness to the finished structure.
- Note: The structure interior is finished with black interior lining fabric. Since this is a double-sided applique only 1 layer per fabric is needed to provide stiffness to the structure.






# EMBROIDERY



## STEP 3

- Load selected design into the machine.
- Example design is 12902-01.
- Thread the machine per the thread chart.
- Stitch Machine Step 1, Gray Front, Black Back Fabric Placement Stitch.



## STEP 4

- Remove the hoop from the machine, but NOT the project from the hoop.
- Lay the hoop on a flat surface.
- Completely cover the placement stitch with the prepared fabric.
- Tape in place to secure.



## STEP 5

- Turn the hoop over and place the fabric, right side up, completely covering the placement stitch.
- Carefully tape to secure. Avoid pushing too hard on the stabilizer to prevent it from dislodging from the hoop.



## STEP 6

- Return the hoop to the machine.
- Stitch Machine Step 2, Cut Line and Tackdown.



## STEP 7

- Remove the hoop from the machine, but NOT the project from the hoop.
- Trim the excess fabric as close to the cut line as possible. If the outermost stitches (cut line) are cut, the inner stitches (tackdown) will hold the applique in place.
- Tip: If the stabilizer is cut or a hole is created while trimming the fabric, use OESD Expert Embroidery Tape WashAway as a patch.



## STEP 8

- Turn the hoop over and trim the excess fabric as close to the cut line as possible.



## STEP 9

- Return the hoop to the machine and stitch the remaining machine steps, per the thread chart.
- Match the bobbin thread to the upper thread throughout.



## STEP 10

- When the design is complete, remove the project from the hoop and trim the stabilizer 1/4" - 1/2" outside the design.



# ASSEMBLY




## STEP 11

- Rinse each piece in warm running water until the design is only slightly tacky.
- Lay right side down on a non-stick surface to dry. Parchment paper or a cooling rack work well to prevent curling. Dry completely.



## STEP 12

- Once dry, press right side down on a Perfect Embroidery Press Cloth.



## STEP 13

- Before assembly, use a utility knife to cut through all the layers of the tab entry, taking care not to cut the satin stitching.
- Reference the Punch Tool Guide on page 26.





# ASSEMBLY




## STEP 14

- Using the OESD Perfect Punch Tool fitted with the 3mm tip, punch out the designated eyelets on all pieces.
- Reference the Punch Tool Guide on page 26.



## STEP 15

- To connect, line up Side Wall 1 FSA (12902-01), Front Wall FSA (12902-02), Side Wall 2 FSA (12902-03) and Back Wall FSA (12902-04) right sides up as shown.
- Thread the sewing machine with matching thread in the top and bobbin.
- Stitch together using a multi-step zigzag stitch (also known as a serpentine stitch). Back stitch at the beginning and end to secure. Trim thread tails.
- Fold and press to shape.
- TIP: An open toe or edge stitch foot is helpful.




# ASSEMBLY



## STEP 16

- Attach one of the Window Boards FSL (12902-05) to the large window of Side Wall 1 FSA (12902-01).



## STEP 17

- Attach the second Window Boards FSL 12902-05 to the window of Side Wall 1 FSA (12902-03).



## STEP 18

- With right sides facing up stitch the two roof pieces Roof 1 FSA (12902-09) and Roof 2 FSA (12902-10) along the long straight edge of the pieces.



# ASSEMBLY



## STEP 19

- Bend at the folds and connect the two buttonettes on the Front Porch FSA (12902-06) to their corresponding eyelets.



## STEP 20

- Insert the two locking tabs from Front Porch FSA (12902-06) into the two bottom entry points on Front Wall FSA (12902-02).






# ASSEMBLY




## STEP 21

- Attach the two remaining buttonettes on the Front Porch FSA (12902-06) to the eyelets on the bottom of the Front Wall FSA (12902-02).



## STEP 22

- Connect the three buttonettes from Front Porch Pillars FSA (12902-08) to the three eyelets on Front Porch Roof FSA (12902-07).






# ASSEMBLY



## STEP 23

- Insert the two locking tabs from the Front Porch Roof FSA (12902-07) into the two entry points on Front Wall FSA (12902-02).



## STEP 24

- From the inside of the structure pull the buttonettes on both sides of Front Porch Pillars FSA (12902-08) through the corresponding eyelets on Front Wall FSA (12902-02).





# ASSEMBLY




## STEP 25

- Insert the two pillars into their corresponding entry points on porch.




## STEP 26

- Connect the three buttonettes of Back Wall FSA (12902-04) to the three eyelets of Side Wall 1 FSA (12902-01) as shown.




## STEP 27

- Attach Roof 1 FSA (12902-09) to the left side of the structure by pulling the five buttonettes from the structure through the five eyelets on the roof as shown.



## STEP 28

- Attach Roof 2 FSA (12902-10) by pulling the five buttonettes on the structure through their corresponding eyelets on the roof as shown.



# ASSEMBLY




## STEP 29

- Roof Spider Webs FSL (12902-11) consists of two webs, one wide web, and one thinner web. Attach the thinner web on the front of the structure by pulling the four buttonettes through the remaining eyelets on the roof.



## STEP 30

- Repeat step 29 for the wider web on the back of the structure.



## STEP 31

- With the right side facing inward, attach Floor FSA (12902-12) to the structure by pulling the four buttonettes through their corresponding eyelets.





## Finishing Touches

- Add tea lights or pixie lights to create a glow.



## Stabilizer

- OESD AquaMesh
- OESD BadgeMaster

## Notions/Tools

- 80/12 Embroidery Ballpoint Titanium needle for extended needle life
- OESD Alligator Clamps
- OESD Button Clips
- OESD Perfect Point and Press Tool

## Isacord Thread Colors

- All OESD designs are digitized with Isacord 40 wt. polyester thread as the top thread and in the bobbin.
- Refer to the thread chart for color specifications.
- Match bobbin thread color to the top thread.

## Instructions

### Step 1 - Hoop

For FSL structures, hoop one layer of OESD AquaMesh and one layer of OESD BadgeMaster. BadgeMaster contains more starch so, combined with the AquaMesh, the lace is more rigid. For other FSL, where a softer lace is desired, hoop two layers of AquaMesh.

### Step 2 - Embroider

Stitch the design per the thread chart with matching thread in the bobbin at each color change. When complete, remove from the hoop and trim away excess stabilizer about 1/4"-1/2" from the stitching.

### Step 3 - Rinse

Rinse remaining stabilizer out in warm running water. For stiffer lace and FSL structures, DO NOT rinse away all of the stabilizer. The lace should be just slightly tacky. For softer lace, rinse until all traces of the stabilizer are removed.

### Step 4 - Dry

Lay right side down flat on a non-stick surface, such as a cooling rack, parchment paper or Teflon sheet. This minimizes the tendency for the lace to curl. Let the pieces dry completely before proceeding with any assembly.

### Step 5 - Press

Once completely dry, press right side down on a OESD Perfect Embroidery Press Cloth.

### Step 6 - Assemble Structure

Note: Specific assembly instructions for a design/collection may be found in the thread chart pdf following the individual design color charts.

Lace must be COMPLETELY DRY before assembly. Wetting the buttonettes or eyelets to assemble is not recommended and may result in them stretching and coming "unbuttoned" when dry.

Use a pair of OESD Alligator Clamps to insert the buttonettes into the eyelets. Insert the tip of the OESD Alligator Clamps into the eyelet, grasp the buttonette and pull through the eyelet. Alternatively, use a stiletto or tweezers to push the buttonette through the eyelet.

## Helpful Tips

### Limp Lace

If the design is not stiff enough, press the lace pieces on the wrong side while applying spray starch. After ironing, spray again with starch and allow to dry completely. This will stiffen the lace pieces nicely and aid in construction. Or easily re-stiffen by diluting some stabilizer scraps in water (or use liquid starch) and dipping the item in the solution. Lay flat to dry.

### Eyelets Too Small

If any of the eyelets appear closed or too small to penetrate with Alligator Clamps, they may be stretched by inserting the small end of the OESD Perfect Point and Press Tool into the eyelet opening and stretching it open wide enough to accommodate the OESD Alligator Clamps.

### Button Clips

During the assembly process, some structures pull on buttonettes that have already been inserted and could pull them out altogether. Putting a Button Clip on the assembled buttonette will keep it in position during the assembly process. Remove the Button Clips when the assembly is complete.


### Alternative Construction Option

In some cases, the buttonettes may be pulled to the inside of a project, instead of being visible on the outside. Insert the OESD Alligator Clamps through the eyelet from the wrong, or inside, of the lace and grasp the corresponding buttonette. Pull the buttonette to the wrong side of the lace. Pulling the buttonettes to the inside may cause stress on the ones already done. Button clips may be placed on the completed buttonette(s) to prevent them from pulling out of the eyelet during construction.

# PUNCH TOOL GUIDES



12902-01



12902-02



12902-03




12902-04




12902-05



12902-06



12902-07



12902-08




- = 2 MM
- = 3 MM
- = 4 MM

CRAFT KNIFE




## ATTENTION

When printing this document, any page scaling or page fitting options in your print dialog box must be turned OFF or set to NONE so that your files will print out at their actual size. Images not printed at actual size will not function as intended.



## TO SAVE PAPER

Only print the desired image by navigating to the image's page, go to File > Print and select "Current page" in the print dialog box. Repeat for each desired image.








# APPLIQUE PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# APPLIQUE PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# APPLIQUE PATTERNS





Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# APPLIQUE PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.







# APPLIQUE PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# MIRRORED PATTERNS







Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# MIRRORED PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# MIRRORED PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.






# MIRRORED PATTERNS





Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# MIRRORED PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.







# FREESTANDING TERRIFYING TOWER



1

Design

# THREAD LIST

## Isacord Thread Colors

0010 Silky White  
0105 Ash Mist  
0108 Cobblestone  
2830 Wild Iris  
4174 Charcoal  
6141 Spring Green

**Note: One spool of 1000 meter thread is adequate for the project unless otherwise noted.**



## Stabilizers

- OESD AquaMesh WashAway
- OESD BadgeMaster WashAway
- OESD StabilStick CutAway
- OESD Fiber Form
- OESD Applique Fuse and Fix

## Fabrics/Textiles

- OESD Luxe Sparkle Vinyl – Black (2 rolls)
- OESD Luxe Sparkle Vinyl – Purple (1 roll)
- OESD Luxe Sparkle Vinyl – Grass Green (1 roll)

## Notions & Tools

- OESD Alligator Clamps
- OESD Button Clips
- OESD Expert Embroidery Tape TearAway
- OESD Expert Embroidery Tape WashAway
- OESD Perfect Punch Tool
- OESD MiniMAT
- OESD Perfect Embroidery Press Cloth
- OESD Grippy GRID
- Embroidery Needle Sharp 75/11 (FSA)
- Embroidery Needle Ballpoint 80/12 (FSL)

## Isacord Thread Colors

- Per the thread chart
- Match bobbin thread to top thread

# SUMMARY



Completed Size: 13 1/2" H x 6" W x 6 1/4" D

12950-01




Requires 1 Design

12950-02




Requires 1 Design

12950-03




Requires 1 Design

12950-04



Requires 1 Design

12950-05




Requires 1 Design

12950-06




Requires 1 Design

12950-07



Requires 1 Design

12950-08



Requires 1 Design


# SUMMARY

12950-09




Requires 1 Design

12950-10



Requires 1 Design

12950-11




Requires 1 Design

12950-12



Requires 1 Design

12950-13




Requires 1 Design

12950-14



Requires 1 Design

12950-15




Requires 1 Design

12950-16



Requires 1 Design

12950-17



Requires 1 Design

12950-18



Requires 1 Design

12950-19



Requires 1 Design

12950-20




Requires 1 Design

12950-21



Requires 1 Design

12950-22



Requires 1 Design



## Notes

The freestanding applique instructions, included in the collection, are general instructions. For demonstration purposes, a sample design that best demonstrates the technique is shown. Fabric and thread requirements will vary by design, but the general technique is the same. All designs are stitched with matching thread, top and bobbin.

**Note:** Some thread colors in instructions have been changed or digitally enhanced for better visibility.

## STEP 1


- Print the mirrored version of the templates (at 100% scale or 1:1 ratio) onto the paper side of Applique Fuse and Fix.
- Cut approximately 1/4" - 1/2" outside the printed applique templates.





## STEP 2

- Cut the Fiber Form 1/4" -1/2" larger than the applique templates.
- Fuse the trimmed templates to the back of the Fiber Form with the paper side of the printed template up. Hold the iron on the template for 10-15 seconds for a secure fuse.



## STEP 3

- Trim the Fiber Form on the edge of the black outline.
- Set aside.




## STEP 4

- Adhere one layer of StabilStick CutAway to the wrong side of all applique vinyl, to provide stiffness to the finished structure.
- Cut the prepared applique vinyl 1/4"-1/2" larger than the templates that are included at the end of the instructions.



## STEP 5

- Hoop one layer of AquaMesh and one layer of BadgeMaster for all designs.



## STEP 6

- Load selected design into the machine.
- Example design is 12950-06.
- Thread the machine per the thread chart.
- Place the hoop on the machine.
- Stitch Machine Step 1, Fiber Form Placement Stitch.



## STEP 7

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- On the back of the Fiber Form, score and remove the paper backing to reveal the adhesive surface.
- Place the Fiber Form within the placement stitching.
- Finger press to secure.



## STEP 8

- Return the hoop to the machine.
- Stitch Machine Step 2, Tackdown and Cut Line.



## STEP 9

- Stitch Machine Step 3, Green Vinyl Placement Stitch.



## STEP 10


- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Completely cover the Fiber Form and the placement stitch with the prepared vinyl.
- Tape in place to secure.





## STEP 11

- Return the hoop to the machine.
- Stitch Machine Step 4, Cut Line and Tackdown.



## STEP 12

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Trim the excess vinyl as close to the cut line stitching as possible.

**Note:** If the outermost stitches (cut line) are cut, the inner stitches (tackdown) will hold the applique in place.

**Tip:** If the stabilizer is cut or a hole is created while trimming the fabric, use OESD Expert Embroidery Tape WashAway as a patch.



## STEP 13

- Return the hoop to the machine.
- Stitch Machine Step 5, Black Vinyl Placement Stitch.



## STEP 14

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Completely cover the Fiber Form and the placement stitch with the prepared vinyl.
- Tape in place to secure.



## STEP 15

- Return the hoop to the machine.
- Stitch Machine Step 6, Cut Line and Tackdown.



## STEP 16

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Trim the excess vinyl as close to the cut line stitching as possible.



## STEP 17

- Return the hoop to the machine.
- Stitch Machine Step 7, Purple Vinyl Placement Stitch.



## STEP 18

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Completely cover the Fiber Form and the placement stitch with the prepared vinyl.
- Tape in place to secure.



## STEP 19

- Return the hoop to the machine.
- Stitch Machine Step 8, Cut Line and Tackdown.





## STEP 20

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Trim the excess vinyl as close to the cut line stitching as possible.



## STEP 21

- Return the hoop to the machine and stitch the remaining steps per the thread chart.
- Match the bobbin thread to the upper thread.



## STEP 22

- When the design is complete, remove the project from the hoop and trim the stabilizer 1/4" - 1/2" outside the design.





## STEP 23

- Rinse in warm running water until the design is only slightly tacky.
- Place right side down on a non-stick surface to dry. Parchment paper or a cooling rack will prevent curling. Dry completely.
- Once dry, press right side down on a Perfect Embroidery Press Cloth.




## STEP 24

- Before assembly, use a craft knife to cut through all the layers of the tab entries.
- Use the OESD MiniMAT and Punch Tool with the 3mm attachment to create the eyelets indicated in the diagram.  
**Tip:** Take care to not cut the satin stitching.
- Reference the Punch Tool Guide on page 27.




## STEP 25

- Line up the 1st Floor wall pieces 12950-01, 12950-02, 12950-03, to connect.
- Thread the sewing machine with matching thread in the top and bobbin.
- Stitch together using a multi-step zigzag stitch.
- Back stitch at the beginning and end to secure.
- Trim thread tails.
- Fold and press into shape.




## STEP 26

- Line up the 1st Floor Roof pieces 12950-07 and 12950-08 to connect.
- Stitch together using a multi-step zigzag stitch.
- Back stitch at the beginning and end to secure.
- Trim thread tails.
- Fold and press into shape.




## STEP 27

- Line up the 2nd Floor wall pieces 12950-13, 12950-14, 12950-15, to connect.
- Stitch together using a multi-step zigzag stitch.
- Back stitch at the beginning and end to secure.
- Trim thread tails.
- Fold and press into shape.




## STEP 28

- Match the eyelets of the Front Door Roof FSA (12950-05) to the buttonettes of the Front Door Walls FSA (12950-04).
- Use Alligator Clamps to pull each buttonette through the corresponding eyelet, using Button Clips to temporarily hold them in place, as needed.



## STEP 29


- Insert the locking tabs of the Front Door assembly into the tab entries of the 1st Floor Front Wall FSA (12950-02).






## STEP 30

- Match the buttonettes of the 1st Floor wall assembly to the eyelets of the 1st Floor Back Wall FSA (12950-06).
- Pull each buttonette through the corresponding eyelet.



## STEP 31


- Match the eyelets of the Balcony Walls FSA (12950-09) to Balcony Floor FSA (12950-10).
- Use Alligator Clamps to pull each buttonette through the corresponding eyelet.






## STEP 32

- Insert the locking tab of the Balcony Walls FSA (12950-09) into the tab entry of the 1st Floor Roof 1 FSA (12950-07).



## STEP 33

- Match the buttonettes of the Balcony Floor FSA (12950-10) to the eyelets of the 1st Floor Roof 1 FSA (12950-07).
- Use Alligator Clamps to pull each buttonette through the corresponding eyelet.



## STEP 34

- Match the buttonettes of the 1st Floor wall assembly to the eyelets of the 1st Floor Roof.
- Pull each buttonette through the corresponding eyelet.



## STEP 35

- Match the 1st Floor Roof Decor Front FSL (12950-11) eyelets to the buttonettes on front side of the 1st Floor Roof.
- Pull each buttonette through the corresponding eyelet.




## STEP 36

- Match the 1st Floor Roof Decor Back FSL (12950-12) eyelets to the buttonettes on back side of the 1st Floor Roof.
- Pull each buttonette through the corresponding eyelet.



## STEP 37



- Match the buttonettes of the 2nd Floor wall assembly to the eyelets of the 2nd Floor Back Wall FSA (12950-16).
- Pull each buttonette through the corresponding eyelet.






## STEP 38

- Match the buttonettes of the 2nd Floor wall assembly to the eyelets of the 2nd Floor Roof FSA (12950-17).
- Pull each buttonette through the corresponding eyelet.



## STEP 39


- Match the 2nd Floor Roof Decor FSL (12950-18) eyelets to the buttonettes on both sides of the 2nd Floor Roof FSA (12950-17).
- Pull each buttonette through the corresponding eyelet.






## STEP 40

- Match the buttonettes of the 3rd Floor Walls FSA (12950-19) to the eyelets of the 3rd Floor Back Wall FSA (12950-20).
- Pull each buttonette through the corresponding eyelet.




## STEP 41

- Match the buttonettes of the 3rd Floor wall assembly to the eyelets of the 3rd Floor Roof FSA (12950-21).
- Pull each buttonette through the corresponding eyelet.



## STEP 42

- Insert the locking tabs of the 3rd Floor assembly into the tab entries of the 2nd Floor Roof FSA (12950-17).



## STEP 43


- Insert the locking tabs of the 2nd Floor assembly into the tab entries of the 1st Floor Roof.



# ASSEMBLY

## STEP 44

- Match the eyelets of the 1st Floor assembly to the buttonettes of the Floor FSA (12950-22).
- Pull each buttonette through the corresponding eyelet.



## STEP 45

- Add tea lights or pixie lights to create a glow.
- The project is complete. Enjoy!





## Stabilizer

- OESD AquaMesh
- OESD BadgeMaster

## Notions/Tools

- 80/12 Embroidery Ballpoint Titanium needle for extended needle life
- OESD Alligator Clamps
- OESD Button Clips
- OESD Perfect Point and Press Tool

## Isacord Thread Colors

- All OESD designs are digitized with Isacord 40 wt. polyester thread as the top thread and in the bobbin.
- Refer to the thread chart for color specifications.
- Match bobbin thread color to the top thread.

## Instructions

### Step 1 - Hoop

For FSL structures, hoop one layer of OESD AquaMesh and one layer of OESD BadgeMaster. BadgeMaster contains more starch so, combined with the AquaMesh, the lace is more rigid. For other FSL, where a softer lace is desired, hoop two layers of AquaMesh.

### Step 2 - Embroider

Stitch the design per the thread chart with matching thread in the bobbin at each color change. When complete, remove from the hoop and trim away excess stabilizer about 1/4"-1/2" from the stitching.

### Step 3 - Rinse

Rinse remaining stabilizer out in warm running water. For stiffer lace and FSL structures, DO NOT rinse away all of the stabilizer. The lace should be just slightly tacky. For softer lace, rinse until all traces of the stabilizer are removed.

### Step 4 - Dry

Lay right side down flat on a non-stick surface, such as a cooling rack, parchment paper or Teflon sheet. This minimizes the tendency for the lace to curl. Let the pieces dry completely before proceeding with any assembly.

### Step 5 - Press

Once completely dry, press right side down on a OESD Perfect Embroidery Press Cloth.

### Step 6 - Assemble Structure

Note: Specific assembly instructions for a design/collection may be found in the thread chart pdf following the individual design color charts.

Lace must be COMPLETELY DRY before assembly. Wetting the buttonettes or eyelets to assemble is not recommended and may result in them stretching and coming "unbuttoned" when dry.

Use a pair of OESD Alligator Clamps to insert the buttonettes into the eyelets. Insert the tip of the OESD Alligator Clamps into the eyelet, grasp the buttonette and pull through the eyelet. Alternatively, use a stiletto or tweezers to push the buttonette through the eyelet.

## Helpful Tips

### Limp Lace

If the design is not stiff enough, press the lace pieces on the wrong side while applying spray starch. After ironing, spray again with starch and allow to dry completely. This will stiffen the lace pieces nicely and aid in construction. Or easily re-stiffen by diluting some stabilizer scraps in water (or use liquid starch) and dipping the item in the solution. Lay flat to dry.

### Eyelets Too Small

If any of the eyelets appear closed or too small to penetrate with Alligator Clamps, they may be stretched by inserting the small end of the OESD Perfect Point and Press Tool into the eyelet opening and stretching it open wide enough to accommodate the OESD Alligator Clamps.

### Button Clips

During the assembly process, some structures pull on buttonettes that have already been inserted and could pull them out altogether. Putting a Button Clip on the assembled buttonette will keep it in position during the assembly process. Remove the Button Clips when the assembly is complete.

### Alternative Construction Option

In some cases, the buttonettes may be pulled to the inside of a project, instead of being visible on the outside. Insert the OESD Alligator Clamps through the eyelet from the wrong, or inside, of the lace and grasp the corresponding buttonette. Pull the buttonette to the wrong side of the lace.

Pulling the buttonettes to the inside may cause stress on the ones already done. Button clips may be placed on the completed buttonette(s) to prevent them from pulling out of the eyelet during construction.



# PUNCH TOOL GUIDES


12950-01




12950-02



12950-03



12950-05




12950-06




12950-07




12950-08




12950-09



12950-17



12950-21




- = 2 MM
- = 3 MM
- = 4 MM

CRAFT KNIFE




## ATTENTION

When printing this document, any page scaling or page fitting options in your print dialog box must be turned OFF or set to NONE so that your files will print out at their actual size. Images not printed at actual size will not function as intended.






## TO SAVE PAPER

Only print the desired image by navigating to the image's page, go to File > Print and select "Current page" in the print dialog box. Repeat for each desired image.




# APPLIQUE PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# APPLIQUE PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.







# APPLIQUE PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.




# APPLIQUE PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.






# APPLIQUE PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# APPLIQUE PATTERNS


Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.






# APPLIQUE PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.




# APPLIQUE PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.






# APPLIQUE PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# APPLIQUE PATTERNS


Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.





# APPLIQUE PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# APPLIQUE PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.

12950-21  
Fiber Form  
& Vinyl




12950-21  
Fiber Form  
& Vinyl

12950-22  
Fiber Form  
& Vinyl

Cut Out


# MIRRORED PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.




# MIRRORED PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



12950-02  
Vinyl  
Mirrored





12950-02  
Vinyl  
Mirrored








# MIRRORED PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.






# MIRRORED PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.




# MIRRORED PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# MIRRORED PATTERNS


Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.






# MIRRORED PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.





# MIRRORED PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.






# MIRRORED PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# MIRRORED PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.







# MIRRORED PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



# MIRRORED PATTERNS

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



### 12950-01 1st Floor Side Wall 1 FSA

Size Inches:                      Size mm:                      Stitch Count:

4.53 X 3.31 in. 115.06 X 84.07 mm 17207 St.

	1.Fiber Form Placement Stitch.....	2830
	2.Cut Line and Tackdown.....	2830
	3.Black Vinyl Placement Stitch .....	2830
	4.Cut Line and Tackdown .....	2830
	5.Purple Vinyl Placement Stitch .....	2830
	6.Cut Line and Tackdown .....	2830
	7.Wall Detail.....	2830
	8.Wall Detail and Lace.....	0105
	9.Window Lace.....	0010
	10.Wall Crack.....	4174
	11.Wall Detail and Lace.....	0108
	12.Wall Cover Stitch and Lace.....	4174
	13.Wall Detail.....	0010



### 12950-02 1st Floor Front Wall FSA

Size Inches:                      Size mm:                      Stitch Count:

6.88 X 5.44 in. 174.75 X 138.18 mm 25277 St.

	1.Fiber Form Placement Stitch.....	2830
	2.Cut Line and Tackdown.....	2830
	3.Green Vinyl Placement Stitch.....	2830
	4.Cut Line and Tackdown.....	2830
	5.Black Vinyl Placement Stitch.....	2830
	6.Cut Line and Tackdown.....	2830
	7.Purple Vinyl Placement Stitch.....	2830
	8.Cut Line and Tackdown.....	2830
	9.Wall Detail.....	2830
	10.Wall Detail.....	6141
	11.Wall Lace and Detail.....	0105
	12.Window Lace.....	0010
	13.Wall Crack.....	4174
	14.Wall Lace and Detail.....	0108
	15.Wall Cover Stitch.....	4174
	16.Wall Detail.....	0010










Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.




## 12950-03 1st Floor Side Wall 2 FSA

Size Inches:                      Size mm:                      Stitch Count:

4.52 X 2.76 in. 114.81 X 70.10 mm 11927 St.

	1.Fiber Form/Purple Vinyl Placement .....	2830
	2.Cut Line and Tackdown.....	2830
	3.Wall Detail.....	2830
	4.Window Lace and Detail.....	0105
	5.Window Lace.....	0010
	6.Lower Side Wall Crack.....	4174
	7.Wall Detail.....	0108
	8.Wall Cover Stitch and Lace.....	4174
	9.Wall Detail.....	0010



## 12950-04 Front Door Walls FSA | 12

Size Inches:                      Size mm:                      Stitch Count:

6.15 X 4.19 in. 156.21 X 106.43 mm 18892 St.

	1.Fiber Form Placement Stitch.....	6141
	2.Cut Line and Tackdown.....	6141
	3.Green Vinyl Placement Stitch .....	6141
	4.Cut Line and Tackdown .....	6141
	5.Black Vinyl Placement Stitch .....	6141
	6.Cut Line and Tackdown .....	6141
	7.Wall Detail.....	6141
	8.Wall and Door Knob.....	0105
	9.Wall Crack.....	4174
	10.Door and Wall Detail.....	0108
	11.Lace Tabs.....	2830
	12.Wall Cover Stitch and Lace.....	4174
	13.Door Detail.....	0010



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

## 12950-05 Front Door Roof FSA | 129

Size Inches:                      Size mm:                      Stitch Count:

4.77 X 2.65 in. 121.16 X 67.31 mm 13299 St.



- 1.Fiber Form/Black Vinyl Placement .....0108
- 2.Cut Line and Tackdown.....0108
- 3.Roof and Lace Tabs.....0108
- 4.Roof Cover Stitch.....4174

## 12950-06 1st Floor Back Wall FSA

Size Inches:                      Size mm:                      Stitch Count:

6.86 X 5.64 in. 174.24 X 143.26 mm 25893 St.



- 1.Fiber Form Placement Stitch.....2830
- 2.Tackdown and Cut Line.....2830
- 3.Green Vinyl Placement Stitch .....2830
- 4.Cut Line and Tackdown .....2830
- 5.Black Vinyl Placement Stitch.....2830
- 6.Cut Line and Tackdown .....2830
- 7.Purple Vinyl Placement Stitch.....2830
- 8.Cut Line and Tackdown .....2830
- 9.Wall Detail.....2830
- 10.Wall Detail.....6141
- 11.Window Lace and Wall.....0105
- 12.Window Lace.....0010
- 13.Lower Back Wall Crack and Door.....4174
- 14.Back Wall Detail.....0108
- 15.Wall Cover Stitch and Lace.....4174
- 16.Wall Detail.....0010







Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



## 12950-07 1st Floor Roof 1 FSA

Size Inches:                      Size mm:                      Stitch Count:

5.89 X 5.85 in. 149.61 X 148.59 mm 28338 St.







	1.Fiber Form/Black Vinyl Placement .....	6141
	2.Cut Line and Tackdown.....	6141
	3.Roof Lace.....	6141
	4.Roof Detail.....	0108
	5.Roof Cover Stitch and Lace.....	4174
	6.Roof Detail.....	0010




## 12950-08 1st Floor Roof 2 FSA

Size Inches:                      Size mm:                      Stitch Count:

5.32 X 5.85 in. 135.13 X 148.59 mm 23928 St.

	1.Fiber Form/Black Vinyl Placement .....	6141
	2.Cut Line and Tackdown .....	6141
	3.Roof Lace.....	6141
	4.Roof Detail.....	0108
	5.Roof Cover Stitch and Lace.....	4174
	6.Roof Detail.....	0010

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



## 12950-09 Balcony Walls FSA

Size Inches:                      Size mm:                      Stitch Count:

7.25 X 4.47 in. 184.15 X 113.54 mm 24687 St.


- 1.Fiber Form/Green Vinyl Placement .....6141
- 2.Cut Line and Tackdown.....6141
- 3.Balcony Detail.....6141
- 4.Lace Tab.....0108
- 5.Balcony Cover Stitch and Lace.....4174

## 12950-10 Balcony Floor FSA

Size Inches:                      Size mm:                      Stitch Count:


1.86 X 4.08 in. 47.24 X 103.63 mm 3832 St.

- 1.Fiber Form/Green Fabric Placement .....6141
- 2.Cut Line and Tackdown.....6141
- 3.Balcony Floor and Lace.....6141
- 4.Balcony Floor Lace Buttons.....0108
- 5.Balcony Floor Cover Stitch.....4174






Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



### 12950-11 1st Floor Roof Dcor Fron

Size Inches:                      Size mm:                      Stitch Count:  
6.28 X 4.64 in. 159.51 X 117.86 mm 12047 St.

■ 1.Single Color Design.....4174




### 12950-12 1st Floor Roof Dcor Back

Size Inches:                      Size mm:                      Stitch Count:  
6.28 X 4.64 in. 159.51 X 117.86 mm 12019 St.

■ 1.Single Color Design.....4174



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



## 12950-13 2nd Floor Side Wall 1 FSA

Size Inches:                      Size mm:                      Stitch Count:  
 3.60 X 3.29 in.    91.44 X 83.57 mm    7743 St.

- 1.Fiber Form/Purple Vinyl Placement .....2830
- 2.Cut Line and Tackdown.....2830
- 3.Wall Detail.....2830
- 4.Lace Tab.....0108
- 5.Wall Cover Stitch and Lace.....4174

## 12950-14 2nd Floor Front Wall FSA

Size Inches:                      Size mm:                      Stitch Count:  
 5.39 X 3.47 in.    136.91 X 88.14 mm    7750 St.

- 1.Fiber Form/Purple Vinyl Placement .....2830
- 2.Cut Line and Tackdown.....2830
- 3.Wall Detail.....2830
- 4.Window Lace.....0010
- 5.Window Lace and Buttons.....0108
- 6.Wall Cover Stitch.....4174
- 7.Window Detail.....0010



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



### 12950-15 2nd Floor Side Wall 2 FSA

Size Inches:                      Size mm:                      Stitch Count:

5.10 X 3.29 in. 129.54 X 83.57 mm 13541 St.

	1.Fiber Form/Purple Vinyl Placement .....	2830
	2.Cut Line and Tackdown.....	2830
	3.Wall Detail.....	2830
	4.Window Lace.....	0105
	5.Window Lace.....	0010
	6.Lace Tab.....	0108
	7.Wall Cover Stitch and Lace.....	4174
	8.Window Detail.....	0010



### 12950-16 2nd Floor Back Wall FSA

Size Inches:                      Size mm:                      Stitch Count:

5.40 X 3.72 in. 137.16 X 94.49 mm 6229 St.

	1.Fiber Form/Purple Vinyl Placement .....	2830
	2.Cut Line and Tackdown.....	2830
	3.Wall Detail.....	2830
	4.Lace Buttons.....	0108
	5.Wall Cover Stitch and Lace.....	4174







Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



## 12950-17 2nd Floor Roof FSA

Size Inches:                      Size mm:                      Stitch Count:

7.76 X 4.73 in. 197.10 X 120.14 mm 34890 St.


	1.Fiber Form/Black Vinyl Placement .....	2830
	2.Cut Line and Tackdown.....	2830
	3.Roof Lace.....	2830
	4.Roof Detail.....	0108
	5.Roof Cover Stitch and Lace.....	4174
	6.Roof Detail.....	0010

## 12950-18 2nd Floor Roof Dcor FSL

Size Inches:                      Size mm:                      Stitch Count:


5.60 X 4.86 in. 142.24 X 123.44 mm 19430 St.

	1.Single Color Design.....	4174
---	----------------------------	------












Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



## 12950-19 3rd Floor Walls FSA

Size Inches:                      Size mm:                      Stitch Count:


7.57 X 5.88 in. 192.28 X 149.35 mm 17641 St.






	1.Fiber Form/Green Vinyl Placement .....	6141
	2.Cut Line and Tackdown.....	6141
	3.Wall Detail.....	6141
	4.Window Lace.....	0105
	5.Window Lace.....	0010
	6.Lace Tabs and Buttons.....	0108
	7.Wall Cover Stitch and Lace.....	4174

## 12950-20 3rd Floor Back Wall FSA

Size Inches:                      Size mm:                      Stitch Count:


5.07 X 3.10 in. 128.78 X 78.74 mm 5421 St.



	1.Fiber Form/Green Vinyl Placement .....	6141
	2.Cut Line and Tackdown.....	6141
	3.Wall Detail.....	6141
	4.Lace Buttons.....	0108
	5.Wall Cover Stitch and Lace.....	4174



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



### 12950-21 3rd Floor Roof FSA

Size Inches:                      Size mm:                      Stitch Count:


7.23 X 3.26 in. 183.64 X 82.80 mm 24854 St.

- 1.Fiber Form/Black Vinyl Placement .....6141
- 2.Cut Line and Tackdown.....6141
- 3.Roof Lace.....6141
- 4.Roof Detail.....0108
- 5.Roof Cover Stitch and Lace.....4174
- 6.Roof Detail.....0010

### 12950-22 Floor FSA | 12950-22

Size Inches:                      Size mm:                      Stitch Count:

4.86 X 4.60 in. 123.44 X 116.84 mm 8079 St.



- 1.Fiber Form/Black Vinyl Placement .....0108
- 2.Cut Line and Tackdown.....0108
- 3.Floor Cover Stitch and Lace.....0108